


BENSON SOLAR SPOTLIGHT

model no. 052-6024 | www.noma.com



IMPORTANT: Please read this manual carefully before assembly and save it for reference.

ASSEMBLY

1. Remove all the following parts from the box: spotlight (A) and ground spike (B).
2. Pull out isolation strip from battery cover underneath the solar panel.
3. Attach spotlight (A) to ground spike (B).
4. Push the light assembly into the ground. **CAUTION:** DO NOT use a hammer.

CHARGING THE BATTERY

Remove the isolation strip from battery cover underneath the solar panel to allow battery to be charged. Allow panel to receive 10–12 hours of full and direct sunlight. Allow the light to run at least 8–12 complete charging and discharging cycles to reach the battery's maximum capacity.

REPLACING THE BATTERY

Pull the locking tab to lift the solar panel. Replace the old battery with a fresh 1.2 V 700 mAh AA Ni-Cd solar rechargeable battery. Lock solar panel back into place.

CARE AND MAINTENANCE

Because solar lights are powered by direct sunlight, they need to be cleaned periodically of dust or dirt so they can easily store energy. They do not work as well during the winter or on cloudy days, so storing them during this time is best.

If your solar light does not turn on at dusk or its nightly run-time is short, it may be caused by one of the following:

1. Battery may not be making contact with terminal.
2. Battery is not fully charged. Be sure the light is in a sunny location where it can receive the maximum amount of full and direct sunlight every day. If the light does not receive enough sunlight during any given day (e.g. due to cloudy or overcast weather conditions), it will be recharged on the next sunny day and resume normal operation. Keeping the panel clean is equally important to ensure maximum charge.
3. The light is installed too close to other light sources, such as streetlights, porch lights, or other solar lights. Relocate or eliminate other light sources.
4. The battery is reaching the end of its useful life and needs to be replaced.

CAUTION

1. Ensure the battery is installed correctly with regard to polarity (+ and -).
2. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium or nickel-metal hydride) batteries.
3. Dispose of the used battery per municipal or provincial law.

This product carries a one (1) year warranty against defects in workmanship and materials. Noma agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MADE IN CHINA

Imported by:

Golden Viking Sports, LLC.

Sumner, WA, USA 98390