

## FLEXIBLE LIGHT STRIP


item no. : CT11510758 model no. : LT-FCB-2W-6X9-19.6Ft-Ex-R-a www.noma.com  
rated : 120 V AC, 60 Hz, 0.12 A maximum extendible length : 248' (75 m), 1.5 A, 180 W

**IMPORTANT:** Please read this manual carefully before assembly and save it for reference.


### ASSEMBLY:

#### HOW TO INSTALL TAPE LIGHT

1) Fix mounting clips with nails or screws onto wooden surfaces. (Fig 1) 2) On a clean smooth surface, use suction cups to mount the light strip. (Fig 2) 3) Mounting clips, suction cups should be evenly spaced and be a maximum of 3' (1 m) apart. (Fig 3) 4) Make sure that the distance between two lines of lighting chains is at least 1/2" (1 cm).  
HINT: For a clean-looking installation and longer lamp life, mount rope light with copper wires horizontal to each other.



(Fig 1)



(Fig 2)



(Fig 3)

#### HOW TO EXTEND TAPE LIGHT

1) Turn the plastic end cap counter-clockwise to remove from the first light strip. 2) Remove power cord from the extension light strip. 3) Connect both ends of the ropes (the male and female halves plug into each other). Make sure all connectors are firmly tightened and secured. 4) Turn the plastic end cap clockwise to lock on the last light strip.




### CAUTION:

a) DO NOT EXCEED THE MAXIMUM NUMBER OF EXTENSIONS OR FLEXIBLE LIGHT LENGTHS PERMITTED BY THE MARKING. b) All units must be unplugged before adding additional segment. c) Maximum total extension length: 124' (38 m). Ensure all connections and the end cap on the last segment are tightly secured to preclude the entry of water. Use only extension segments recommended by the manufacturer of this system.

### How to replace the fuse:

This plug contains an electrical fuse a safety feature.

a) Disconnect power before replacing the fuse. b) Grasp plug and remove from the receptacle or other outlet device. c) Do not unplug by pulling on the cord. d) Unscrew the fuse access cover on top of attachment plug. e) Remove old fuse carefully. f) Never attempt to replace the fuse with a higher watt fuse. Use only 5 A, 125 V fuse. Failure to do so may be a fire hazard. g) Set new fuse in holder. h) Reinstall the fuse access cover.



### Caution:

Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.

## ⚠ CAUTION:

1) Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuit or outlet. 2) Use only outdoor extension cords, such as type SOW, STW, SJOW or SJTW. 3) Do not install closer than 10' (3 m) from a swimming pool surface.

### Warning: Risk of Fire and Shock

1) Do not cover this product as the covering may cause the flexible light to overheat and melt or ignite. 2) Do not use if there is any damage to the light or cord insulation. Inspect periodically. 3) Do not operate with the flexible light tightly coiled. To prevent overheating do not allow contact between flexible light cables and parts of light cables. Maintain at least 1/2" (12 mm) spacing between flexible light cables or parts of light cables. 4) Do not puncture, cut, shorten, or splice the flexible light. 5) Do not route the cord or flexible light cable through walls, doors, windows or any like part of the building structure. 6) Do not use if there is any damage to the light or cord insulation. Inspect periodically. 7) Do not submerge flexible light in liquids. 8) Secure this flexible light cable using only the hangers or clips provided. Do not secure this product or its cord with staples, nails, or like means that may damage the insulation. 9) Do not install on gates or doors, where subject to flexing. 10) Do not install in cabinets, tanks or enclosures of any kind.

### IMPORTANT SAFETY INSTRUCTIONS:

This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

This Noma® product carries a one (1) year warranty against defects in workmanship and materials. Noma agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MADE IN CHINA  
Imported by Golden Viking Sports, LLC. Summer, WA USA 98390