


## 3' Colour-changing Tabletop Blue Tree

model no. CT11517079 www.noma.com

**IMPORTANT:** Please read this manual carefully before assembly and save it for reference.



### ASSEMBLY:

- 1) This product comes packed in two pieces: the tree and the stand.
- 2) Place the stand on a sturdy surface and insert the tree into the stand.
- 3) Shape the tree by arranging the branches into the desired position. Finished look should be natural-looking and full.
- 4) Connect the plug of the light set to the power supply.
- 5) You can press the controller to choose the LED light colour, (warm white, multi-colour, warm white + multi-colour).
- 6) Your tree is ready to be decorated and enjoyed.

**SHAPING:** The tree is shipped from the factory with the tips of each branch compressed to the centre. Each branch tip must be shaped to its proper position to give the tree a natural look. This is done by gently grasping the branch tips and spreading them out away from the centre of the tree, working from the bottom up.

**STORAGE:** Branch tips should be carefully pressed back towards the centre when tree is disassembled for storage. Store in original carton, in a cool, dry location protected from sunlight.

### Specialty

#### Product contains 3-light colour switch:

1. Warm White
2. Multi colour
3. Warm White+Multi colour

#### FCC marking for adaptor:

- "This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation." CTC Triangle (USA) LLC, 14000 24th Street E, Sumner, WA, USA 98390

#### FCC instruction for adaptor:

- "Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."
- "NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."

#### If the lights do not work:

1. Ensure the power outlet is working correctly.
2. Ensure the plug is connected properly between the tree and the transformer socket.

#### **⚠ CAUTION:**

1. For indoor use only.
2. Keep away from any source of flame or heat.
3. This is a Christmas decoration. This is not a toy. Keep away from babies and children.

This Noma<sup>®</sup> product carries a one (1) year warranty against defects in workmanship and materials. Noma Canada agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MADE IN CHINA

Imported by: CTC Triangle (USA) LLC

Address: 14000 24th Street E, Sumner, WA, USA 98390



### FCC marking & instruction

### Caution

### Warranty