Grip Propane Scale

User's Manual



Don't guess when you have directions.

Thanks for choosing this grip propane scale. In order to make sure you will use it correctly and keep long life of the scale. please read this manual carefully before use.

Summarize

This grip propane scale is designed for quickly weighing tanks of 5lb, 10lb,20lb,30lb,40lb. It is equipped with high precision sensor, clear display screen, durable weight hook, convenient for carrying and storage. It weigh tanks and directly shows the percentage of remaining propane and icon of propane tank with

bars inside it to show how full or empty the tank it is.

Install battery



(Diagrammatic drawing)

Tank selection

Please prepare 2 x AAA batteries in advance. And open the battery covers as following steps:

Step 1: Push the battery covers outwards slightly.

Step 2: Slightly tilt the battery cover upwards and gently remove the lid.

Step 3: Insert the AAA batteries in the right direction and close the lid properly.




Operation Instruction

1. Power on: press"ON/OFF" button to power on.

The factory default setting is to weigh the percentage of 20 Lbs propane tank. Please press "TANK SIZE" button to choose the tank spec you are going to weigh.

The scale unit will automatically remember last same tank size when it was turned off unless user removes the battery or batteries run out.

If batteries run out, or user removes the battery from scale, it will get back to factory default setting 20 lbs tank after power on.




2. Tank selection: Press button "TANK SIZE" to choose the tank size you are going to weigh.

Tank size will be switched circularly in size up direction.

For example, if the scale is on the 10 Lbs and a press on the "TANK SIZE" button will move the scale to the 20 Lbs, another press will move it to the 30 Lbs and so on.

When it gets to 40 Lbs, a press will move it to the 5 Lbs then each press will move it one size up.



- 3. Check and make sure the weight hook is tightened up with the scale, then hang the scale and make it upright, hang the propane tank onto the weight hook of scale, and then lift the scale by hand. Please make sure to keep the display of scale to be horizontal as the ground level, ensure the whole set of scale and propane tank are stable without shaking during measuring process, otherwise it will affect the accuracy of measuring data. After weighing, the display will show and hold the measuring data on the screen.
- 4. There is a tank symbol on the left of display screen, which shows 5 grids, each grid stands for 20%.
 - 1 grid means propane remained between 0%-20%
 - 2 grids mean propane remained between 21%-40%
 - 3 grids means propane remained between 41%-60%
 - 4 grids means propage remained between 61%-80%
 - Full 5 grids means propane remains between 81-100%
- 5. The result of each weighing to stay on the screen for more than 5 seconds for reading data. After releasing the object being weighed, or if click on/off or any other button, the scale will respond to your operation.
- 6. After weighing 1 item, and change to measure the next one, please don't touch the scale hook when scale is automatically resetting to zero in order not to affect the accuracy. Or you can press "ON/OFF" to reset to zero before measuring the next item.
- 7. If no operation for 60 seconds, the unit will automatically power off.

Note:

- 1. Keep it upright when the scale on the process of power on.
- 2. Grasp the handle to weigh. Try your best to keep the scale horizontally, otherwise the data will be not exact.
- 3. Don't impact violently or rough press to the scale.
- 4. Do not use chemical detergent for cleaning. Please use dry soft cloth to clean the unit gently.
- 5. When battery is lower power, the will show "Lo" on the display screen as a indication. Please replace battery in time. If you don't use the scale for long time, please take out the batteries out to prevent corrosion of the circuit.