



Instructions for Assembly – COMO (WALL)


- Un-pack the box, carefully.
- **DO NOT MIX** the **WOOD BLADES** of **ONE** fan with **OTHER**. **SUPPLIED** in **SETS** of **3**




- A. Lay the SOLID WOOD Blades in Sets.
 B. All BLADES are numbed ending with A or B or C




- C. Remove the Screws from the blade holder and keep it aside.



- D. Match Number on BLADE with Motor Blade Holder
 E. Turn the BLADE over (Number STICKER must HIDE between the BASE & LEG)
 F. “THIS SIDE BACK” Sticker should face the WALL or BACK of Blade Holder.



- E. Tighten provided Screws.
 F. REPEAT from Step C for Other BLADES.



FAN SPEED CONTROL

Fan has IN-BUILT speed control by PULL CHAIN

TO CHANGE SPEED - Pull chain Lightly to hear a click and fan speed will cycle.
OFF - FULL - MEDIUM - SLOW - OFF

CHANGE DIRECTION of FAN with **HAND**. Hold **WITH BOTH HANDS** to **CHANGE DIRECTION**.

FAN MOUNTING

