

STEPPED DISPLAY STAGING - STYLE 4 F4(01)

Assembly Instructions




COMPONENTS

Components	Approx. Length Of Stand										
	2'	4'	6'	8'	10'	12'	14'	16'	18'	20'	SPEC
Tube A 21½" Connector	7	14	21	28	35	42	49	56	63	70	
Tube B 5 5/8" Leg	6	9	12	15	18	21	24	27	30	33	
Tube C 8½" Spacer	8	12	16	20	24	28	32	36	40	44	
Tube D 9" Upright	6	9	12	15	18	21	24	27	30	33	
Tube E 19" Upright	2	3	4	5	6	7	8	9	10	11	
3 Way Joints	6	6	6	6	6	6	6	6	6	6	6
4 Way Joints	6	9	12	15	18	21	24	27	30	33	
5 Way Joints	2	5	8	11	14	17	20	23	26	29	
6 Way Joints	--	1	2	3	4	5	6	7	8	9	
Caps	6	9	12	15	18	21	24	27	30	33	
Trays	2	4	6	8	10	12	14	16	18	20	


Left, Right and Mid Sections are to be made out of the above components

Left Hand Sections	1	1	1	1	1	1	1	1	1	1	1
Right Hand Sections	1	1	1	1	1	1	1	1	1	1	1
Mid Sections	--	1	2	3	4	5	6	7	8	9	


1. Please check the components.
2. Assemble the upright sections as illustrated and join using connector tubes A.
3. The joints are a tight fit and should be knocked into the tube up to their 'shoulders'. Assembly is best achieved working on a firm surface, using a wooden or rubber mallet.



LEFT HAND UPRIGHT
1 PER STAND



MID UPRIGHT
1 FOR 4', 2 FOR 6' ETC.



RIGHT HAND UPRIGHT
1 PER STAND