


  
**HALO<sup>®</sup>**  
**SLEEK3500<sup>™</sup>**

---

**POWERFUL UNIVERSAL  
PORTABLE CHARGER**



**OPERATING INSTRUCTIONS**  
PLEASE READ BEFORE OPERATING THIS EQUIPMENT

## **HALO SLEEK 3500**

Thank you for choosing HALO. The HALO SLEEK 3500 comes equipped with a built-in AC wall plug and built-in cables, lightning tip and micro USB built-in cables. Also additional USB output to allow charging of any devices using standard USB output and additional micro USB input to recharge the device.

Please read the operating instructions carefully before using the HALO SLEEK 3500.

# **TABLE OF CONTENTS**

Included Items

Operating Instructions

Maintenance and Care


Safety Precautions

Specifications

Warranty and Contact Information

## INCLUDED ITEMS

- HALO SLEEK 3500
- Micro-USB Cable
- Operating Instructions



## LOCATION OF CONTROLS

- 1 | AC Input
- 2 | Built-in Micro USB Cable
- 3 | Built-in Lightning Cable
- 4 | Micro USB Input Port
- 5 | USB Output Port

## **OPERATING INSTRUCTIONS**

Prior to first use, it is recommended to fully charge the HALO SLEEK 3500.

### **TURNING YOUR HALO SLEEK 3500 ON/OFF**

The HALO SLEEK 3500 is equipped with HALO Smart Charge Technology. This means the HALO SLEEK 3500 will automatically detect when an electronic device is connected. The LED Battery Indicator will display four solid blue lights when fully charged. The HALO SLEEK 3500 will automatically shut off after 5 seconds if not in use.

### **CHARGING THE HALO SLEEK 3500**

The HALO SLEEK 3500 operates on a rechargeable, Li-ion battery. First, use the Standard USB to Micro USB Cable (included) and connect the Micro USB tip into the Micro USB port on the HALO SLEEK 3500. Next, connect the Standard USB end into your computer's USB port or a USB adapter (not included).

While charging, the LED Battery Indicator will turn on and flash. When battery is fully charged, the LED Battery Indicator will stop flashing, disconnect the Standard USB to Micro USB Cable.

Note: The Micro USB Charging Port located on this unit is only used for charging the internal battery of the HALO SLEEK 3500.

## **CHARGING ELECTRONIC DEVICES**

To charge electronic devices, use the built-in cables, gently pull the top of the respective cable. The HALO SLEEK 3500 comes with both built-in micro USB cable and lightning cable. Simply, plug the correct tip into your device and it will automatically begin to charge.

To charge electronic devices using your personal cable, plug the Standard USB end of the charging cable that came with your electronic device into the HALO SLEEK 3500, then plug the other end of that cable into your electronic device. Charging will automatically begin.

## **CHARGING TWO ELECTRONIC DEVICES**

You can simultaneously charge two devices by using both the built-in micro USB cable and lightning cable. You can also charge a third device using the cable that came with your personal electronic device by plugging the USB end into the HALO SLEEK 3500.

## HALO SLEEK 3500 LEVEL INDICATORS

Indicator Lights	How to Read	Amount of Charge
● ○ ○ ○	One solid light	0%-25%
● ● ○ ○	Two solid lights	26%-50%
● ● ● ○	Three solid lights	51%-75%
● ● ● ●	Four solid lights	76%-100%

## HALO SLEEK 3500 LEVEL INDICATORS: WHILE CHARGING

Indicator Lights	How to Read	Amount of Charge
⚡ ○ ○ ○	All four lights blinking	0%-25%
● ⚡ ○ ○	First light solid, other lights blinking	26%-50%
● ● ⚡ ○	First two lights solid, other lights blinking	51%-75%
● ● ● ⚡	First three lights solid, light blinking	76%-99%
● ● ● ●	All four lights solid	100% fully charged

## **MAINTENANCE AND CARE**

After prolonged use, the internal battery will become weak and the operation may become intermittent. When the battery is very low, it will rapidly flash to alert you to recharge the internal battery as soon as possible.

To maximize battery life: once the battery is fully discharged, immediately recharge (regardless of whether you plan to use this unit or not). If you do not plan to use the battery for an extended period of time (one week or longer), we recommend that you fully charge the battery. For longer periods of storage, please recharge the battery at least every two months to maintain the battery in optimum condition.

## **SAFETY PRECAUTIONS**

This HALO SLEEK 3500 has been designed and manufactured to ensure your personal safety when used in the directed manner. Improper use can result in potential hazard.

Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference.

- The HALO SLEEK 3500 should not be used near water or wet areas such as bathtubs, showers, bathrooms, sinks, or swimming pools.
- To reduce the risk of fire or electric shock, do not

expose the HALO SLEEK 3500 to rain or moisture. Keep the HALO SLEEK 3500 away from dripping, splashing, or any objects filled with liquids. Do not place anything on HALO SLEEK 3500.

- Keep away from heat sources, including but not limited to: open flame sources, radiators, stoves, ovens, cars, and amplifiers that produce heat.
- Do not expose HALO SLEEK 3500 or batteries to fire or sunshine.
- Do not puncture, crush or subject to mechanical shock.
- Do not disassemble.
- Unplug the charger when batteries are fully charged or not in use.
- Li-ion batteries must be recycled. Do not dispose of in the trash.

## **SPECIFICATIONS**

Battery Capacity: 3500mAh

Micro USB Input Charging: 5V  $\Rightarrow$  2.0A

Built-in micro USB cable output: 5V  $\Rightarrow$  2.0A max

Built-in lightning cable output: 5V  $\Rightarrow$  1.0A

USB Output 1: 5V  $\Rightarrow$  1.0A

Dimensions: 129 x 65.6 x 13 mm

Weight: 160 g

Working Temperature: 0°C to 45°C

Working Humidity: Max 85%

## COMPLIANCE WITH FCC REGULATIONS

“This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

“Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.”

“NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **LIMITED WARRANTY**

Halo International SEZC LTD warrants its products to be free from defects in material and workmanship under normal use. Conditions are as follows:

- During the first 90 days from date of purchase, Halo International SEZC LTD will repair or replace the defective product.
- Halo International SEZC LTD will, subject to inspection, repair the defective product or replace it with a new or reconditioned unit. The return must be accompanied by a Return Merchandise Authorization (RMA) number to be issued upon request, and must be shipped prepaid. We do not offer shipping rebates at this time.
- Warranty is void if the product has been improperly handled or misused in any way, or if the label and/or

bar-coded warranty label has been removed or tampered with.

- Where applicable, all requests for warranty returns must be accompanied by a proof of purchase.
- The warranty does not extend to the electronic equipment that is used or which incorporates with any of our products and accessories. Halo International SEZC LTD shall not be held responsible for the improper use of its products.
- For all questions or exchange requests, please call 888-907-6274, or email us at [support@BestHALO.com](mailto:support@BestHALO.com)

This Limited Warranty sets forth the full scope of HALO's obligations and liabilities with respect to the product. All implied warranties, including, without limitation, implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of this Limited Warranty. In no event shall HALO be liable for any incidental, special, consequential or punitive damages or any damages or losses of or to electronic equipment or products that are used with any of HALO's products.



FOR TECHNICAL SUPPORT PLEASE  
EMAIL US AT:

**SUPPORT@BESTHALO.COM**

OR

CALL US AT: **888-907-6274**

**HALO INTERNATIONAL SEZC LTD**  
**68 WEST BAY ROAD**  
**GEORGETOWN, GRAND CAYMAN, KY1-1003**



**WWW.BESTHALO.COM**

Designed by Halo International  
SEZC LTD. in Cayman Islands  
Patent Pending. Made in China.

