




HALO[®]

SHINE 3000 WITH FASHION CABLE

**POWERFUL UNIVERSAL
PORTABLE CHARGER**



OPERATING INSTRUCTIONS

HALO SHINE 3000

Thank you for choosing HALO. From HALO, the SHINE 3000 with fashion cable is the most perfect and chic pairing! The SHINE is a compact portable charger perfect for anyone to throw in a bag or back pocket, and the fashion cable is made from high quality leather and metal, creating the most stylish and convenient accessory combo for while you are on the go. The SHINE 3000 is capable of charging any small electronic devices, including but not limited to mobile phones, cameras, iPods, and gaming systems using standard USB output. The SHINE 3000 also features a flashlight at the top & its micro USB input allows for seamless recharge. Comes in multiple colors.


Please read the operating instructions carefully before using the HALO SHINE 3000.

CONTENTS

Included Items	1
Operating Instructions	3
Maintenance and Care	6
Safety Precautions	6
Specifications	7
Warranty and Contact Information	9

INCLUDED ITEMS

- Halo Shine 3000
- 2 in 1 Fashion Cable
- Operating Instructions



LOCATION OF CONTROLS

- 1 | Power On/Off Button
- 2 | LED Battery Indicator Lights
- 3 | Micro-USB input port
- 4 | USB Output Port
- 5 | Flashlight Power Button
- 6 | Flashlight

HALO SHINE 3000 POWER LEVEL INDICATORS

Indicator Lights	How to Read	Amount of Charge
● ○ ○ ○	One solid light	0%-25%
● ● ○ ○	Two solid lights	26%-50%
● ● ● ○	Three solid lights	51%-75%
● ● ● ●	Four solid lights	76%-100%

HALO SHINE 3000 POWER LEVEL INDICATORS: WHILE CHARGING

Indicator Lights	How to Read	Amount of Charge
☼ ○ ○ ○	First light blinking	0%-25%
● ☼ ○ ○	First light solid, second light blinking	26%-50%
● ● ☼ ○	First two lights solid, third light blinking	51%-75%
● ● ● ☼	First three lights solid, fourth blinking	76%-99%
● ● ● ●	All four lights solid	100% fully charged

OPERATING INSTRUCTIONS

Prior to first use, it is recommended to fully charge the HALO SHINE 3000.

Press the Power On/Off Button to display the power level on the HALO SHINE 3000. The LED battery indicator will display four solid blue lights when fully charged.

CHARGING THE HALO SHINE 3000

Using the supplied Micro-USB cable, plug the micro-USB end of the cable into the micro-USB input port of the HALO SHINE 3000 and plug the other USB connector into a computer or an AC adapter with a USB 5V output.

CHARGING YOUR PERSONAL ELECTRONIC DEVICE

Using the Micro-USB cable, plug the standard end of the USB connector into the USB output port of the HALO SHINE 3000. You may also use your own USB cable that was supplied with your personal electronic device. The HALO SHINE 3000 will automatically begin charging your electronic device.

TURNING ON/OFF YOUR HALO SHINE 3000

The HALO SHINE 3000 will automatically turn on and begin charging as soon as it is plugged into your personal electronic device. To preserve the battery, the HALO SHINE 3000 will automatically turn off if the electronic device is fully charged and no longer drawing power. When the HALO SHINE 3000 is


manually unplugged from your device it will automatically turn off after 30 seconds. The HALO SHINE 3000 may also be turned off by manually double clicking the power button.

FLASHLIGHT OPERATION

1. Press the flashlight button to turn the flashlight on.
2. When the flashlight is on, press the flashlight button again to activate the Dim Mode.
3. When the Dim Mode is on, press the flashlight button again to activate the SOS Mode.
4. When the SOS Mode is on, press the flashlight button again to turn off.

2 IN 1 FASHION CABLE INSTRUCTIONS

1. Plug the USB end directly into any USB port.
2. To charge Apple devices, attach the lighting tip over the Micro USB tip. Plug the lightning tip into your Apple device to begin charging.
3. To charge Android devices, plug the Micro USB adapter located underneath the lightning tip into your device to begin charging.



SYNC INSTRUCTIONS

1. Plug the USB end directly into any USB port.
2. To sync Apple devices, attach the lightning tip over the Micro USB tip. Plug the lightning tip into your Apple device to begin syncing.
3. To sync Android devices, plug the Micro USB adapter located underneath the lightning tip into your device to begin syncing.

MADE FOR IPOD/IPHONE/IPAD

The HALO 2 IN 1 CABLE is Apple certified. "Made for iPod," "Made for iPhone," and "Made for iPad" means that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance. AirPlay, iPad, iPhone, iPod, iPod classic, iPod nano, iPod touch, and Retina are trademarks of Apple Inc., registered in the U.S. and other countries. iPad Air, iPad mini, and Lightning is a trademarks of Apple Inc.

MAINTENANCE AND CARE

After prolonged use, the internal battery will become weak and the operation may become intermittent. When the battery is very low, the first battery indicator will flash to alert you to recharge the internal battery as soon as possible.

To maximize battery life: once the battery is fully discharged, immediately recharge (regardless of whether you plan to use this unit or not). If you do not plan to use the battery for an extended period of time (one week or longer), we recommend that you fully charge the battery. For longer periods of storage, please recharge the battery at least every two months to maintain the battery in optimum condition.

SAFETY PRECAUTIONS

This HALO SHINE 3000 has been designed and manufactured to ensure your personal safety when used in the directed manner. Improper use can result in potential hazard.

Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference.

- Warning: The product has a strobe light effect when played in the SOS mode which has the ability to cause headaches and possible seizures.
- The HALO SHINE 3000 should not be used near water or wet areas such as bathtubs, showers, bathrooms, sinks, swimming pools or basements.
- To reduce the risk of fire or electric shock, do not expose the HALO SHINE 3000 to rain or moisture. Keep the HALO SHINE

3000 away from dripping, splashing, or any objects filled with liquids. Do not place anything on HALO SHINE 3000.

- Keep away from heat sources, including but not limited to: open flame sources, radiators, stoves, ovens, cars, and amplifiers that produce heat.
- Do not expose HALO SHINE 3000 or batteries to fire or sunshine.
- Do not puncture, crush or subject to mechanical shock.
- Do not disassemble .
- Unplug the charger when batteries are fully charged or not in use.
- Li-ion batteries must be recycled. Do not dispose of in the trash

SPECIFICATIONS

Model: HS-3000

Battery Capacity: 3000mAh

Micro USB Input: 5V  1A

USB Output: 5V  2.1A

Dimensions (W x H x D): .87 inches x 4.25 inches x .87 inches

Weight: 70 grams

Charging Time: ~1 hour 40 minutes

Working Temperature: 5°F to 120°F

COMPLIANCE WITH FCC REGULATIONS

“This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause

harmful interference, and (2) this device must accept any interference received, including interference that may cause

undesired operation.”

“Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.”

“NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

LIMITED WARRANTY

HALO International SEZC LTD warrants its products to be free from defects in material and workmanship under normal use. Conditions are as follows:

- During the first 90 days from date of purchase, Halo International SEZC LTD will repair or replace the defective product.
- HALO International SEZC LTD will, subject to inspection, repair the defective product or replace it with a new or reconditioned unit. The return must be accompanied by a Return Merchandise Authorization (RMA) number to be issued upon request, and must be shipped prepaid. We do not offer shipping rebates at this time.
- Warranty is void if the product has been improperly handled or misused in any way, or if the label and/or bar-coded warranty label has been removed or tampered with.
- Where applicable, all requests for warranty returns must be accompanied by a proof of purchase.
- The warranty does not extend to the electronic equipment that is used or which incorporates with any of our products and accessories.

HALO International SEZC LTD shall not be held responsible for the improper use of its products.

- For all questions or exchange requests, please call: US: 888-907-6274; UK: 020 3318 9944, or email us at support@BestHALO.com

- This Limited Warranty sets forth the full scope of HALO's obligations and liabilities with respect to the product. All implied warranties, including, without limitation, implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of this Limited Warranty. In no event shall HALO be liable for any incidental, special, consequential or punitive damages or any damages or losses of or to electronic equipment or products that are used with any of HALO's products.



FOR TECHNICAL SUPPORT

EMAIL US AT:
SUPPORT@BESTHALO.COM
OR
CALL US AT:
888-907-6274

HALO INTERNATIONAL SEZC LTD.
90 NORTH CHURCH STREET,
GEORGE TOWN, GRAND CAYMAN

WWW.BESTHALO.COM