



Manual

Customer Service: hello@waatr.com • 1-833-642-7659

User Manual

Charging

To charge, place the magnetic charger on top of the cap over the charging pins and connect the USB plug to a wall adapter. Full charge takes about 3-4 hours.



Breathing **ORANGE** light while charging



Solid **GREEN** light when fully charged



Scan for instructional videos

Battery Life

Press the activation button once to check the battery life.



GREEN light indicates 40% - 100% charge



ORANGE light indicates 11% - 39% charge



RED light indicates 1% - 10% charge

Pure Mode Purification

Press activation button twice to activate Pure Mode. This mode will activate UV-C LED for 1 min. to purify water. During this process, the indicator light will breathe **BLUE**. Once the purification is completed, the indicator light will flash **GREEN**.



Press 2X for Pure Mode

Ultra-Pure Mode Purification

Press activation button thrice to activate Ultra-Pure Mode. This mode will activate UV-C LED for 3 min. to maximize purification, destroying 99.999999% of germs. During this process, the indicator light will breathe **BLUE**. Once the purification is completed, the indicator light will flash **GREEN**.



Press 3X for Ultra-Pure Mode

Self-Cleaning Feature

To conserve battery, PureMax ships with the self-cleaning feature deactivated. To activate the self-cleaning feature, LONG PRESS the activation button for 3 seconds; the indicator light will blink **GREEN** upon successful activation. To deactivate this feature, LONG PRESS the activation button for 3 seconds; the indicator light will blink **RED** upon successful deactivation. Once self-cleaning mode is turned ON, PureMax will automatically activate once every hour for 15 seconds to keep the bottle odor-free. While self-cleaning is in-progress, indicator light will breathe **BLUE**.



GREEN
Self-cleaning ON



RED
Self-cleaning OFF



BLUE
Self-cleaning IN PROGRESS

Drink Water Reminder

To conserve battery, PureMax ships from with the drink reminder feature deactivated. To activate the drink reminder feature, press the activation button 5 times; the indicator light will blink **ORANGE** upon successful activation. To deactivate this feature, press the activation button 5 times; the indicator light will blink **RED** upon successful deactivation. Once the drink reminder is turned ON, PureMax will slow blink **GREEN** 3 times every 30 minutes for up to 2 hours. If the user does not remove the cap for more than 2 hours, the drink reminder will go into standby mode until the user removes the cap.



Flashing **RED**:
Hydration Reminders: OFF



Flashing **ORANGE**:
Hydration Reminders: ON



Flashing **GREEN**:
Hydration Reminders: IN PROGRESS

UV-C Smart Safety Sensor

To protect users from accidental eye exposure, PureMax is built with a smart safety sensor. This sensor deactivates the UV-C LED once the cap is removed from the bottle. If the user removes the cap from the bottle during Pure or Ultra-Pure Mode or self-cleaning mode is in progress, the indicator LED will blink **RED** for 3 seconds and then the UV-C LED will turn off. This prevents user from accidental exposure to the UV-C light.



Flashing **RED**
Smart Safety Sensor ACTIVATED

Quick Start:

Step 1: Charge The Cap

Charge the PureMax cap fully before use. Tap activation button to indicates battery life.
Green light indicates 40% - 100%
Orange light indicates 11% - 39%
Red light indicates 1% - 10%



Step 2: Prime The Filter

PureMax filter should be soaked in a liter of water ~15 minutes before first use. Once soaking is done, flush the filter under running water for ~2 mins.



Step 3: Filter

Install the primed filter into the PureMax cap as shown in the image. Apply slight force while installing to ensure the filter fits snugly into the cap.



Step 4: Fill

Fill bottle with water and screw the PureMax cap.



Step 5: Purify

Press activation button two times to start Pure Mode or three times for Ultra-Pure Mode purification. Pure Mode purification takes one minutes, and Ultra-Pure Mode purification takes 3 minutes.



Step 6: Drink

Drink confidently once the purification is completed.



UV Sanitizer

Sanitize objects on the go (like phones, keys, masks, etc.) by placing them inside the bottle and UV treating them in Ultra-Pure Mode, eliminating 99.99% of germs on the surface of the objects.



Phone



Keys



Mask

One Cap Fits All

Depending on your usage, you can purchase PureMax bottle-only products from WAATR.COM in various sizes. PureMax cap currently fits 25, 32, and 40 oz PureMax bottles. Note: WAATR will be introducing more bottle size options in the future.



25 Oz / 740ml



32 Oz / 940ml



40 Oz / 1180ml

Filter Choices

We know filters are not "one size fits all". So, we designed the cartridge to be easily interchangeable to accommodate a variety of cartridges that we will be introducing in the near future.


We designed our first three sets of cartridges to satisfy your thirst:

- 1) PURIST
- 2) ARTESIAN
- 3) ALKALINE



Purist:

Removes Lead, Mercury, Manganese, Zinc, Iron, Copper, Benzene, Chlorine (taste & odor). Eliminates particulates and debris.



Artesian:

Purist Filter + Proprietary blend of minerals to enhance the taste of normal water to ARTESIAN tasting water.



Alkaline:

Purist Filter + Proprietary blend of minerals to enhance the pH of the water to 9.2

Safety Precautions

- Do not expose eyes to UV-C light.
- NOT DISHWASHER SAFE. Hand wash only.
- Change the filters once every two months to ensure optimal performance.

Warranty

Lifetime warranty summary: WAATR warrants its products against the defects in materials and workmanship for its lifetime from the date of original purchase. WAATR will replace the covered product using new or fully refurbished product depending on the availability.

WAATR does not cover shipping under the warranty.



Scan for instructional videos

- waatrofficial
- waatr
- www.waatr.com