

Assembly and operating instructions Hammock

OYSTER



Shown is the oyster

CrazyChair® is the internationally registered trademark of Pimiento OHG, for exclusive, high-quality hanging chairs, hammocks, stainless steel stands and matching accessories.

The complete range of services, such as idea, design, development, production, marketing and sales is carried out at several locations in Germany.



Pimiento OHG - Crazy Chair • MAIL info@crazychair.de • WEB www.crazychair.de

GA20210506-E-OYSTER

Scope of delivery

please check for completeness

1 Hammock Oyster

2 spreader bars, stainless steel

1 utensil bag

2 suspension ropes each 2 m

2 safety shackles, stainless steel (tied in)

1 large pillow, high quality filling

Not included:

Appropriate ropes are required for suspension over longer distances.

High quality ropes, weatherproof, seawater resistant, with 1,000 kg breaking load, can be ordered from us.

Description:

The OYSTER has been designed extra luxuriously: large, comfortable, stable, comfortable, aesthetic, high-quality workmanship, for 2 persons or alone, ergonomic, weatherproof, with a huge cushion, practical utensil bag. For the perfect lying comfort in a hammock with spreader bars and 2-point suspension, the lying surface is made of 5 double-layered longitudinal strips, with padding. This stabilises the width and allows two people to lie in it. The huge cushion with high-quality, weatherproof filling is cuddly and comfortable at the same time. The utensil pocket for books, tablets, glasses, etc., which is attached to the head-side spreader bar, is practical and easily accessible. Safety shackles made of stainless steel are attached at both ends for suspension.

Technical data that convince:

weatherproof hammock with 2 spreader bars

lying surface 125 cm x 215 cm, made of 5 sheets

Clamping length from 260 cm

double layer, padded, spacer fabric

Own weight approx. 10 kg

Resting load 250 kg

Product characteristics:

very stable, does not tilt, much lying comfort

ergonomic reclining quality

skin-friendly, breathable mesh fabric

is pleasantly airy in strong sunlight

insensitive to sun/UV, rain, sea water

easy-care, robust, durable

1. Inserting the utensil bag.

The practical bag has a sewn „tunnel channel“.

One of the spreader bars can be pushed through this channel before being inserted into the two retaining thimbles. We have defined the area with the sewn-on Crazy Chair label as the hammock headboard. There should be the spreader bar with the utensil bag.

2. Insert spreader bars.

The two spreader bars are inserted at each end of the hammock. Before the spreader bars are put into the black „thimbles“ for the first time, you should shape them with your fingers a little bit as a „trough“ so that the bar ends can be put in more easily and get a good grip.



3. Hanging the hammock.

Choose a suitable place to hang the hammock, e.g. on a hammock stand, between 2 trees or on 2 fixed attachment points.

V4A safety shackles are tied at both ends of the hammock. Fold the two ends of the suspension rope in the appropriate length as a loop, which corresponds to the distance of the rope suspension. Tie the two ends of the rope with a simple looped knot. Attach the cables to the selected suspension point, which should be approx. 2.60 m to 4.50 m apart.

The ropes are knotted at an attachment height of approx. 140 cm, e.g. on a tree, a hook or a stand. If the distance is greater, the two suspension points of the OYSTER must be correspondingly higher.

4. Use of the hammock.

The hammock should be stretched taut for easy entry/exit without moving strongly out of the bend of the body. When standing in front of the hammock, the edge of the hammock is at waist level. You stand in front of the hammock in the middle and hold the longitudinal outer edge with both hands. Pull it under your bottom and sit in the middle of the hammock.

From the sitting position you turn your upper body sideways to the back in the lying position and swing your legs into the hammock.

When you lie down in the hammock for the first time, all knots are loaded by the body weight and the ropes are tightened in length. All thimbles get the perfect shape and the hammock gets its final position. It is therefore a good idea to adjust the hammock position to the perfect desired height (on both suspension ropes).



5. Useful tips on transport, storage and care.

The OYSTER is deliberately heavy due to its design. In strong winds the hammock could still turn. Depending on the intensity of the „windbeat“, it can also be stressful for the material or micro-grid fabric. The windblow can cause the coloured filament of the covering to rub and partially peel off. This results in unsightly colour peeling. However, the stability of the hammock is maintained.

Note: Damage to material due to strong wind is not covered by the warranty, as it can be avoided if used correctly.

If, for example, you remove the two spreader bars from the thimbles of the stretched OYSTER, the hammock will collapse flat and have less wind attack surface.

But she must not rub the floor in this condition. Better still, take the hammock down in time and do not expose it to strong winds.

The All-Weather material was developed for outdoor use (can also be used indoors) and is resistant to sun and moisture.

To clean the hammock, a sponge with water or a little bit of soapy water is sufficient. Under no circumstances use the high-pressure cleaner or the washing machine.

The Crazy Chair logo is placed on the lying side in the head area for orientation. The black straps point to the underside of the hammock.

Use and safety instructions

Read the manual before use and keep it for further questions.

The Crazy Chair hammock is ideal for relaxing, you lie back-friendly and relaxed lengthwise. The lying load is 250 kg.

The suspension points must be adjusted to the weight of the person or the weight to be carried and provide a secure attachment.

Regularly check that the suspension ropes and knots are correctly positioned. Protect ropes from chafing, especially on edges or sharp corners. If metal rubs against metal during fastening, it is necessary to grease the areas regularly.

It is not a (children's) swing or play equipment. Children should only use the hammock in the presence of adults and should not be left unattended.

Keep the packaging away from babies or small children, as there is a danger of suffocation if it is put over their head.

Do not hang the hammock near open fireplaces, fireplace, barbecue, etc.

Please note that rodents/mice like to nibble on the fabric - so please protect against them.

Warranty

The Crazy Chair hammock is handmade with great care and subjected to multiple inspections. If something is not in order at delivery or if there is a defect in material or workmanship, a repair or replacement will be made within the framework of the legal warranty.

What is used is at the discretion of the manufacturer. No liability is assumed for any consequential damage or failures beyond this.

The warranty is valid for normal use in private use with careful handling (no commercial or public use). Improper handling, environmental influences, colour changes, damage due to external influences are not covered by the warranty claims.

We are happy to help.

For questions, advice, product information, we are available as manufacturer. If you need our advice on hanging, have any questions regarding the use of the product, accessories or other items of the Crazy Chair Collection, please contact us by phone or e-mail.

Crazy Chair is an internationally registered trademark. Crazy Chair develops, designs and produces in Germany. More about Crazy Chair can be found on the Internet at www.crazychair.de

Hammock Stands

For the OYSTER there is the perfectly matching stainless steel stand LAZY.

