



Scan for more details www.petlibro.com

PETLIBRO Capsule Automatic Pet Water Fountain

Model: PLWF002

©Libro Corp. All Rights Reserved.

Manufacturer: Shenzhen Libro Technology Co., Limited Address: Building 3, Cloud Park, Shenzhen, China, 518129

JP Importer: 株式会社神州

Made in China

PLWF002 V1.0

CAN ICES-3 (B)/NMB-3(B)















This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAPSULE

Automatic Pet Water Fountain

User Manual

Model: PLWF002

Before using the product, please read this manual thoroughly and retain it for future reference

Contents

English

Safety Precautions	1
Product Overview	2
How to Use	4
Care Instructions	5
How to Clean the Pump	6
Troubleshooting	7
Specifications	8
Warranty	8

Safety Precautions

! Warning


- Dispose of all packaging materials properly. Keep the polybags away from children and pets as these bags could cause suffocation.
- . Do NOT allow children to play with, in or around the pet water fountain.
- To avoid injury, please keep close supervision when the appliance is used near children.
- Do NOT use the water fountain with pets not able to reach the water tray or with any physical disability.
- . Do NOT place any foreign object in the water tank.
- Do NOT disassemble the pet fountain other than components as instructed in this User Manual.
- Do NOT use the pet fountain for anything other than its intended use.
- Only use attachments recommended or sold by the manufacturer. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition. Do NOT modify the pet fountain.
- Do NOT operate any appliance if the unit is malfunctioning or has been damaged. Do not attempt repairs on the device yourself. Contact our customer service immediately for further instructions.
- Be sure to disconnect the power supply for safety when the appliance is not in use.
- Please disconnect the power supply before maintaining and cleaning the machine.
- Always unplug the appliance when not in use; or before putting on or taking
 off parts and before cleaning.
- . The power adapter and wire plug must not be flooded during cleaning.
- . This product is for indoor use only.
- This product is not allowed to run without water.
- Never pull the electrical power cord to remove the plug from the wall outlet.
- If the plug of this device gets wet, turn off the electricity of that wall outlet. Do NOT attempt to unplug.
- Check the device after installation. Do NOT plug in if there is water on the contact points or plug.
- . To avoid tripping, always position the power cord out of the way of foot traffic.
- . Do not use the appliance in the bathroom.
- Change the filter every 2 weeks or when the flow rate has noticeably reduced.
 For two or more cats, you may need to replace the filters more regularly if it heromes blocked


Caution

- Do NOT allow pets to chew on or swallow any parts. If you are concerned about the power cord, purchase a cord conduit (a hard-plastic protector) at any hardware store to protect the power cord.
- If an extension cord is necessary, one unit with a proper rating should be used.
- Do NOT install or store the pet water fountain where it will be exposed to weather or temperatures below 0°C / 40°F.
- Read and observe all important notices listed on the pet water fountain and in the packaging.

Product Overview

Front View





10) Cord Slot

11) Water Tank

7) Water pump with power cord 8) Foam Filter

9) Charger

How To Use

Step 1




 Soak the filter in a clean bowl. for 5 minutes

Notes:

1) The filter must be fully soaked before the fountain is turned on: otherwise, water may not flow through the filter smoothly and cause spillage. 2) Do not soak the filter in the water tank of the fountain in case of any surface dust.


Step 2



 Position the pump according to the bottom slot shape. Press the pump to make the suction cups under the pump stick tightly. Put the cord in the slot.

Note: The pump must be fixed in the right position in the tank.


Step 3



• Install the silicone pipe on the pump. Add water to the tank.

Note: Keep the water level between the Min and Max level. The pump will fail if it runs dry.

Step 4



• Install the filter tray and place the filter on the filter tray. Press down firmly to make sure the pipe outlet comes out.

Step 5










. Install the water trav. Whether to install the spout depends on your pet's drinking preference.






· Connect the power adapter.

Care Instructions

- 1) Replace the filter and foam every 2 weeks.
- 2) Clean the pump and fountain every 2 weeks.
- 3) To extend the life of pump, please add water before starting the machine.

How to clean the pump

Step 1



•Remove the pump cover.

Note: The foam filter is in the pump cover, change the foam every 2 weeks.

Step 3




 Use the brush to clean the parts with water.

Step 2



•Remove the impeller cover.

Step 3



•Remove the impeller by the brush hook.

Troubleshooting

Problem	Solution
Water keeps spilling out of the water tray.	The filter may not be fully soaked. Please soak the filter in a clean bowl (not in the water tank) for 5 minutes before the first use.
The pump stops working.	1) Fill in water between MIN and MAX. The pump will fail if it runs dry. 2) Clean the pump, water tank, and drinking basin. 3) If the above solutions don't work, please contact us at support@petlibro.com.
How often should I change the filters? Where to get them?	It's recommended to replace the filter and sponge every 2 weeks. Please contact us at support@petlibro.com to purchase new filters.
Why do I need to soak the filter before first use?	The filters absorb more water (and therefore clean more water) when they're wet and expanded. Soaking the filter removes particulate matter that may have settled on the filter.
Water output speed slows down.	For the first use (or reuse after long-time storage), the water pump needs to discharge air, it's normal if the water output speed slows down.

6

Specifications

Model	PLWF002
Power Adapter	Input: 100-240V 50/60Hz
	Output: 5V/1A
Material	ABS
Water Tank Capacity	2.1 L
Dimensions	225x141.5x140 mm / 8.9 x 5.6 x5.5 inch
Net Weight	700g/24.7oz

Warranty

- •12-month warranty
- •Life-time support

Please contact our customer service at support@petlibro.com for warranty extension or any questions about the product. For more information, please visit www.petlibro.com.