

Operating mode is selected by means of DIP switches on-board:




Switch status and mode selection:

	1	2	3	4	5	6	7	8
CH340 connect to ESP8266 (upload sketch)	OFF	OFF	OFF	OFF	ON	ON	ON	NoUSE
CH340 connect to ESP8266 (connect)	OFF	OFF	OFF	OFF	ON	ON	OFF	NoUSE
CH340 connect to ATmega2560 (upload sketch)	OFF	OFF	ON	ON	OFF	OFF	OFF	NoUSE
CH340 connect to Mega2560 COM3 connect to ESP8266	ON	ON	ON	ON	OFF	OFF	OFF	NoUSE
ATMega2560 + ESP8266	ON	ON	OFF	OFF	OFF	OFF	OFF	NoUSE
All modules work independent	OFF	NoUSE						


Also, have switch for change of connecting port between ATmega2560 and ESP8266



After choosing the mode of the board can proceed to set up the IDE It is important that when the ESP8266 module is programming, it is necessary to press the button "Mode"




To begin open the Arduino IDE programming environment and go to settings




Then in the window that appears in the row, Additional Boards Manager URLs (marked in red) insert the below link


http://arduino.esp8266.com/stable/package_esp8266com_index.json for installation in Arduino IDE additional scripts that would work with the modules ESP8266 and click OK



Then go to the Tools> Board> Boards Manager




In the window that appears, scroll through the list down to the script esp8266 by ESP8266 Community and click.




In the lower right corner will be able to select the version of the software, select the version 2.1.0 (the newest) and click the Install button



After installation, close the window and go to Tools> Board and see the list of available devices on the chip programming ESP8266



Next, you need to select the card as shown in the picture (Generic ESP8266 module)



Select the upload speed - 115200

```
Tools Help
     Auto Format
                                  Ctrl+T
     Archive Sketch
     Fix Encoding & Reload
     Serial Monitor
                                  Ctrl+Shift+M
     Serial Plotter
                                  Ctrl+Shift+L
    ESP8266 Sketch Data Upload
     WiFi101 Firmware Updater
     Board: "Generic ESP8266 Module"
     Flash Mode: "DIO"
     Flash Frequency: "40MHz"
     CPU Frequency: "80 MHz"
     Flash Size: "512K (64K SPIFFS)"
     Debug port: "Disabled"
     Debug Level: "None"
     Reset Method: "ck"
     Upload Speed: "115200"
     Port
     Get Board Info
======test sketch for ATmega2560=======
void setup()
Serial3.begin(115200);
pinMode(13,OUTPUT);
delay(500);
Serial3.println("AT+CIPMUX=1");
delay(2000);
Serial3.println("AT+CIPSERVER=1,5000");
delay(2000);
Serial3.println("AT+CIPSTO=3600");
delay(2000);
void loop()
while(Serial3.available())
char Rdata;
Rdata=Serial3.read();
if(Rdata=='A'|Rdata=='a')
digitalWrite(13,HIGH);
```

```
delay(50);
}
else if(Rdata=='B'|Rdata=='b')
{
    digitalWrite(13,LOW);
    delay(10);
    digitalWrite(13,HIGH);
    delay(10);
    digitalWrite(13,LOW);
}
else
{
    digitalWrite(13,LOW);
}
}
```