Mi Wireless Switch User Manual



Product Overview

Mi Wireless Switch is a new remote control switch with low power consumption. It supports three control modes, which are single tap, double tap, and press and hold. Based on the configuration, it can realize automatic control over other smart devices via the hub to intelligently perform various scenarios.

*This product is for indoor use only, and needs to be used along with a device with gateway capabilities.



Connecting with Mi Home / Xiaomi Home App

This product works with Mi Home / Xiaomi Home app*. Control your device with Mi Home / Xiaomi Home app. Scan the OR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search ""Mi Home / Xiaomi Home"" in the app Store to download and install it. Open Mi Home / Xiaomi Home app, tap "+" on the upper right. Select "Mi Wireless Switch", and then follow prompts to add your device.

*The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.



Note: The version of the app might have been updated, please follow the instructions based on the current app version.

Installation

Effective Range Test: Press the reset button at the desired location. If the hub beeps, it indicates that the sensor can communicate effectively with the hub.

Option 1: Place it directly in the desired location.

Option 2: Remove the protective film to stick it at the desired location.

* Make sure the surface is clean and dry. *Do not install them on any metal surface.



① Remove the protective film

@Place it directly in the

desired location.

Specifications

Model: WXKG01LM

Item Dimensions: $50 \times 50 \times 15$ mm Wireless Connectivity: Zigbee

Battery Type: CR2032

Operating Temperature: -10°C to 50°C

Operating Humidity: 0-95% RH, non-condensing

Maximum Transmit Power: 10.5 dBm Working Frequency: 2405 MHz~2480 MHz

 Hereby, Lumi United Technology Co., Ltd., declares that the radio equipment type [Mi Wireless Switch, WXKG01LM] is in compliance with Directive

2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.mi.com/global/service/support/declaration.html



All products bearing this symbol are waste electrical and electronic

equipment (WEEE as in directive

2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of

waste electrical and electronic equipment. appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points. Symbol for "ENVIRONMENT PROTECTION -Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local Authority or retailer for recycling advice".



Symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall

be handed over to the applicable collection point for the recycling of electrical and electronic equipment.