




SMART WIFI SOCKET

Model : Sonoff S26




Parameter:

Input voltage: 100-240V AC 50/60Hz
Output voltage: 100-240V AC 50/60Hz
Max. load: 2200W/10A
WiFi standard: 2.4GHz b/g/n

V1.3

Checklist before using the device

- Your smart phone or tablet has connected to a 2.4G WiFi with internet.
- You have the correct WiFi password.
- Your smart phone or tablet must have access to APP Store, Google Play.
- Make sure your router is MAC-open.




User Guide

- 1 Start with "EWelink" APP.




- 2 Register an EWelink account.
- 3 If you have EWelink account, just log in.

- 4 Plug S26 into power socket, power it up. The green WiFi LED will blink.



- 5 Press and hold the button for 7 seconds until the green LED blinks rapidly.

- 6 Tap + on EWelink app.



- 7

- 8 Input your WiFi SSID & password.
- 9 Name your device to complete.
- 10 When the WiFi LED is on , the device is online. Start to control now!

Q: My device on the app stays "Offline" ?

A: The new added device needs 1-2min to connect to WiFi and the Internet. If it stays offline for a long time, please judge the problem by the green LED status:
Green led quickly blinks one time every second: S26 failed to connect to WiFi:
①Maybe you have entered wrong WiFi password.
②The S26 is too far away from the router, which causes a weak WiFi signal. Please take it closer. If still failed, try to delete and add again.
Green led quickly blinks twice every second: S26 has connected to WiFi but failed to connect to server. Please check your network connectivity.

Scan the right QR code to read the pairing instructions for Amazon Echo and Google Nest.



Scan to download EWelink free APP




Scan to read the detailed user guide



WiFi智能插座

型号 : Sonoff S26



产品参数:

输入电压 : 100-240V AC 50/60Hz
输出电压 : 100-240V AC 50/60Hz
最大功率 : 2200W/10A
WiFi标准 : 2.4G b/g/n

V1.3

使用该设备前请检查以下事项 :

- 您的智能手机或平板已连接上一个能上网的2.4G WiFi.
- 使用安卓系统的手机或平板, 系统必须是4.0以上版本.
- 使用苹果手机或iPad必须能够访问APP商店并下载APP.
- 如果您的无线路由器设置了MAC地址过滤, 请先进入路由器后台关闭MAC过滤功能.



产品使用说明


- 1 在各大应用市场搜索“易微联”或扫码下载安装。



下载免费“易微联”APP

- 2 安装过程如有提示权限请求请选择允许。
- 3 注册账号并登录易微联。

- 4 将S26插入插座, 通电。绿色WiFi指示灯闪烁。



- 5 长按S26插座上的配置按钮大约7秒, 直到绿色指示灯快速闪烁, 松开。此时设备处于待配对添加状态。



- 6 进入易微联, 点击APP上的添加按钮 +



- 7

- 8 输入您的WiFi名和密码, 下一步。
- 9 待APP自动添加完成, 给设备命名, 完成添加。
- 10 当设备的WiFi指示灯长亮, 即可进行远程控制。

常见问题: 设备添加成功后, 显示离线, 无法控制?

答: 设备刚添加成功后, 需要一两分钟时间连接您的路由器并联网。如果长时间还是显示不在线, 请根据设备绿色指示灯的状态来判断:

- 绿灯一闪快闪一下: 说明S26没有连上您的WiFi。
①可能是WiFi密码输入不正确。
②可能是S26离您的路由器太远, 信号太弱, 或环境有干扰。请先将S26靠近路由器, 如无改善, 请拔下S26, 然后再重新添加一遍。
- ③S26不能识别5G的WiFi, 请选择2.4G的WiFi重新添加。
- ④检查您的路由器后台是否开启MAC地址过滤。如有, 请关闭。

绿灯一闪快闪2下: 说明S26已连接到了WiFi但没有连上外网。请确认您的WiFi当前连接外网是否稳定。正常。如时好时坏, 频繁出现这种双闪情况, 说明您的网络不稳定, 并非产品原因。

*扫码阅读使用NEST、ALEXA语音关联控制的教程。



ewelink.coolkit.cc
扫码阅读最新的使用说明和帮助

物料: S26说明书

材料: 105g铜板 四色印刷 手风琴4折页

展开尺寸: 200x90mm 折后尺寸: 50x90mm