

User Manual

1. Parts

2. Accessories

3. Technical Specifications

8. Warrantv

4. Features

5. How To Use

6. Safety Instructions

7. Cleanina Instructions

Thank you for purchasing the Buck Naked Express electronic cigarette! Please read all operating and safety instructions before using.



## Accessories



# Technical Specifications

- Working Voltage/Current: DC 3.0-4.2V 0.8-1.6A
- Resistance:  $2.3-3.0\Omega$
- Charging Voltage/Current: 5V/650mA
- USB Charger Voltage/Current: 4.2V/420mA Cycle Timer: 10s (±1S)
- Quiescent Current: 4.2V/≤10uA (Typical 3uA)

- Features
- 5-Click Locking System
- 10 Second Auto-Shutoff Timer
- High-Capacity Rechargeable Battery
- Compact Size & Energy Efficient
- Charger/Battery Designed To Prevent Overcharging

• 1.6ml Energy Efficient Heating Element

6 Month Limited Warranty

### How To Use

- Charaina Screw the battery onto the charger and connect USB plug into a dedicated USB port, LED light will flash 3 times to indicate charging has begun. Charger light will glow red whole charging, changing to green once fully charged.
- Filling The Cartridge Tank Unscrew mouthpiece and pour e-liquid into opening, using a dropper or needle-tip bottle to avoid spilling. Do not fill beyond 1.6ml line. Reattach mouthpiece and wipe away any spilled e-liquid.



- 5-Click Locking System Your Buck Naked Express is equipped with a locking feature to prevent it from turning on unexpectedly. To lock/unlock, push the LED button 5 times within 3 seconds. The LED light will flash 3 times to indicate it is locked/unlocked.
- Operating Screw the cartridge tank onto the battery. Press the LED button and inhale at the same time. The LED button will light up during operation. Release the button after inhaling.



### Safety Instructions

- Do not store battery or other parts in extreme temperature.
- Avoid long exposure to direct sunlight.
- Do not submerge in water.
- If exterior parts get wet, do not operate until completely dry.
- Do not operate with empty cartridge tank.
- Always remove cartridge tank from battery during storage. Use only Buck Naked brand chargers and accessories.

Cleaning Instructions Use a damp wash cloth to wipe down and exterior parts, using a mild soap or approved cleaner to remove any stubborn spills or residues. To clean the cartridge tank, place a small amount of filtered water into the empty tank and hold down the LED button for one complete cycle. Repeat this process until the water has evaporated or the tank is

adequately clean. Let all parts dry before resuming use. Failure to follow all operating and safety instructions may cause damage or serious injury and will void the warranty!

6 Month Limited Warranty

• The Buck Naked Express is augranteed from manufacturer defects or malfunction from date of purchase for a period of 6 months for the battery and 3 months for the cartridge tank. This limited warranty protects against manufacturer defect under normal use and does not apply to normal wear & tear; improper use; accidental damage from dropping or submerging in liquid; improper cleaning; neglect; or any other damage that is not a result of defective materials or workmanship. If your Buck Naked Express qualifies for servicing, we will repair or replace, at our discretion and expense, any defective parts or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all repairs/replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the Buck Naked Express will void the warranty. Warranty is non-transferable. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



For warranty servicing, contact us at:

www.BuckNakedECigs.com