


USER MANUAL 使用手冊 用戶手冊




---

# BEANS PRO 2

ANC TRUE WIRELESS EARBUDS

ANC真無線藍牙耳機 ANC真无线蓝牙耳机





# INDEX

<b>English</b> .....	<b>2</b>
繁體中文 .....	<b>8</b>
简体中文 .....	<b>14</b>

**thecoopidea**

# CONTENTS




Charging Case



Earbuds



Type-C Cable



Eartips x 6 Pairs



Genuine Leather Strap

## PICK THE RIGHT TIPS

### i) Bass Eartips



The enhanced bass frequencies penetrate deeper into the ear canal, reducing the length of the sound waves' path, for an exceptional listening experience and maximum comfort. Lessens the hissing sounds for a more moderate, heavier sound and that enhances the sound of the music.

### ii) Balance Eartips



The tight fit to the shape of the ear canal gives a super airtight effect, providing powerful noise cancellation and delivering the most realistic, high-resolution music without external interference.

# OVERVIEW

- |                           |                             |
|---------------------------|-----------------------------|
| <b>A</b> Magnetic Closure | <b>F</b> Charging Interface |
| <b>B</b> Strap Holder     | <b>G</b> Microphone         |
| <b>C</b> Charging Pin     | <b>H</b> Touch Interface    |
| <b>D</b> Power Indicator  | <b>I</b> LED Indicator      |
| <b>E</b> Eartips          | <b>J</b> Type-C Input       |

# NOISE CANCELLING

Tap **H** on Left side once to cycle through:

1. Active Noise Cancellation
2. Ambient Sound Mode ON
3. Ambient Sound Mode OFF



## Active Noise Cancellation (ANC)

ANC microphone analyze and block out environmental and in-ear noises respectively.

## Ambient Sound Mode

Ambient Sound Mode uses the microphones built into the left and right sides to allow you to hear ambient sound even while wearing headphones. Pay attention to the sounds around you to enjoy listening to music safely.

# CHARGING

## Charging Earbuds

☼ White.....Charging

☼ Off .....Charged




## Charging Case (Unplugged)




Flash OFF OFF ..... **LOW**

ON OFF ON .....  Placed Correctly

ON ON ON ..... 



## Charging the Case



Power Source  
(DC 5V/1A)

\*It is recommended to use the supplied charging cable to provide the optimal charging experience

## Charging Case (Charging)




Flash OFF OFF ..... 


ON Flash OFF ..... 

ON ON Flash ..... 


ON ON ON ..... 







# WEARING



# PAIRING



Connects each other automatically.


1. L   R flash blue ... Connecting
2. L  flashes / 1S ... Connected  
R  flashes off

"Bip" sound will be heard on each earbud .

Make sure your device's Bluetooth function is turned on

Look for "THECOOPIDEA BEANS PRO 2" from the bluetooth device list and press connect.

Indicator on Earbuds should be off if the it is successfully paired.



# CONTROLS



Play/Pause			
Next track			2S
Previous track		2S	
Volume up			
Volume down			
ANC/Ambient ON/OFF			
Siri/Google assistant			
Pick up call			or
Hang up			or
Reject call		2S	or  2S
Power On	Pick up earbuds from charging case		
Power Off	Place earbuds back to charging case		
Manual On	3S	and	3S
Manual Off	5S	and	5S
Auto Power Off	Idle for 10 minutes		

## Hard Reset

Turn off earbuds, hold both buttons for 10 secs and release, "Bip" sound will be heard. Earbuds will turn off, then on again, the earbuds will pair within 15 secs

TAP    HOLD

\*Control only applicable when both earbuds are used together



# SPECIFICATION

<b>Model Number</b>	CP-TW08
<b>Color Options</b>	Sakura, Olive, Matt Black
<b>Bluetooth Version</b>	5.1
<b>Frequency Range</b>	20-20KHz
<b>Impedance</b>	32Ω
<b>Sensitivity</b>	98dB ± 3 dB
<b>Driver Size</b>	10mm
<b>Support Codex</b>	AAC, SBC
<b>Support Profile</b>	HFP, HSP, A2DP, AVRCP
<b>Play Time</b>	Up To 3H (ANC On), 4H (ANC Off)
<b>OTG Play Time</b>	Up To 21H (ANC On), 25H (ANC Off)
<b>Standby Time</b>	80H
<b>Recharge Time</b>	1H (Charging Case), 1H (Earphones)
<b>Battery Capacity</b>	380mAh (Charging case), 40mAh (Earphones)
<b>Case Dimensions</b>	47 x 47 x 30mm (LxWxH)
<b>Case Net Weight</b>	31g
<b>Earbuds Dimensions</b>	31 x 15 x 24mm (LxWxH) (Each)
<b>Earbuds Net Weight</b>	4g (Each)
<b>Waterproof Rating</b>	IPX5 (Earphones)
<b>Safety Protections</b>	Short Circuit, Over Charge, Over Discharge

# WARNING

**A**lways store the earbuds in the charging case and safely protected.

Avoid storing the earbuds in hot or cold environments to prevent depletion of the battery capacity

Avoid storing the earbuds for extended periods of time without recharging them.

If the earbuds or the charging case become dirty, it is recommended to clean them with a soft cloth that has been dampened with clean water.

The OS version of mobile devices may affect performance of BEANS PRO 2, it is recommended to update the OS of your mobile device to the latest version before use.

Don't put the BEANS PRO 2 into Charging case while there is moist. Doing so can cause severe damage to the electronics or housing of BEANS PRO 2. BEANS PRO 2 Charging case is not waterproof.

Store the product in a dry area. Keep away from fire, heat, moist and erosive materials.

Remove from power source once the product is fully charged. Extended periods of over-charging will decrease battery life.

It is strongly recommended to clean and dry BEANS PRO 2 properly when it has been exposed to water and sweat.

Do not use rough chemical such as soap or cleanser to scrub the product.

Do not disassemble, damage, or expose the product to water or fire. Warranty will be voided by any misuse of the product.

If the battery is expanded or emits smell, stop using the product immediately.

## 內容物




充電盒



耳機



Type-C 連接線



矽膠耳塞 x 6 對



真皮吊帶

## 挑選合適的矽膠耳塞

### i) 低音矽膠耳塞



增強低頻，能進入耳道更深處，減少音場聲波擴散路徑上的阻礙，享有不同凡響的聆聽體驗與頂級舒適感。削弱部分齒音，聲音更加溫和厚重，增加音樂的可聽性。

### ii) 平衡矽膠耳塞



超強密閉效果，能夠服貼耳道的形狀，提供強大的降噪效能，在隔絕外界干擾下，傳遞最真實、高還原的音樂。

## 總覽

**A** 磁性蓋

**B** 吊帶扣

**C** 充電接腳

**D** 電源指示燈

**E** 矽膠耳塞

**F** 充電介面

**G** 麥克風

**H** 觸控介面

**I** LED 指示燈

**J** Type-C 輸入

## 降噪

輕觸左側 **H** 一次以切換：

1. 主動式降噪
2. 環境聲音模式開啟
3. 環境聲音模式關閉



### 主動式降噪(ANC)

ANC 麥克風可分別分析並阻絕環境和耳內噪音。

### 環境聲音模式

環境聲音模式使用左右兩側內建的麥克風，讓您即使戴著耳機也能聽到環境聲音。請注意周遭聲音，以便安全地享受音樂。

# 充電

## 為耳機充電

✧ 白燈 ..... 正在充電

✧ 熄滅 ..... 充電完畢



## 充電盒（未插電）

✧ ✧ ✧


閃爍 熄滅 熄滅 ..... 電量不足

亮起 熄滅 亮起 ..... 正確放置


亮起 亮起 亮起 ..... 



正確放置



## 為充電盒充電



電源  
(DC 5V/1A)

\*建議使用隨附的充電線，以提供最佳充電體驗

## 充電盒（正在充電）


✧ ✧ ✧

閃爍 熄滅 熄滅 ..... 


亮起 閃爍 熄滅 ..... 

亮起 亮起 閃爍 ..... 


亮起 亮起 亮起 ..... 



## 配戴



## 配對



自動互相連線。

1. 左 ✨ ✨ 右 閃爍藍燈 ..... 正在連線

2. 左 ✨ 閃爍 / 1 秒 ..... 已連線  
右 ✨ 指示燈熄滅

將在兩個耳機上聽到警示音。

確定裝置的藍牙功能已開啟

從藍牙裝置清單中尋找「THECOOPIDEA BEANS PRO 2」，按「連線」。

如果配對成功，耳機上的指示燈應熄滅。



# 控制



播放 / 暫停			
下一首			2秒
上一首			2秒
音量調高			
音量調低			
ANC / 環境聲音 開啟 / 關閉			
Siri/Google 助理			
接聽			或
掛斷			或
拒接			或
電源開啟	將耳機從充電盒中取出		
電源關閉	將耳機放回充電盒中		
手動開啟		及	
手動關閉		及	
自動關機	閒置 10 分鐘		

## 硬重設

關閉耳機，按住兩個按鈕 10 秒後放開，會聽到「嗶」聲。再開啟耳機，將在 15 秒內彼此配對

● 輕觸    長按

\*控制僅在兩個耳機搭配使用時才適用

# 規格

型號	CP-TW08
顏色選項	櫻花粉紅、橄欖綠、消光黑
藍牙版本	5.1
頻率範圍	20-20KHz
阻抗	32Ω
靈敏度	98dB ± 3 dB
單體尺寸	10mm
支援編解碼器	AAC, SBC
支援設定檔	HFP, HSP, A2DP, AVRCP
播放時間	最長 3小時 (ANC 開啟), 4小時 (ANC 關閉)
OTG 播放時間	最長 21小時 (ANC 開啟), 25小時 (ANC 關閉)
待機時間	80小時
充電時間	1 小時 (充電盒), 1 小時 (耳機)
電池容量	380mAh (充電盒), 40mAh (耳機)
充電盒尺寸	47 x 47 x 30mm (長x寬x高)
充電盒淨重	31克
耳機尺寸	31 x 15 x 24mm (長x寬x高) (每個)
耳機淨重	4克 (每個)
防水等級	IPX5 (耳機)
安全防護	短路、過充電、過放電

# 警告

請務必將耳機存放在充電盒中並妥善保護。

請避免將耳塞存放在炎熱或寒冷環境中，以防止電池電量耗盡。

請避免長時間存放耳機而不充電。

如果耳機或充電盒變髒，建議用沾有清水的軟布清潔。

本產品支援“蘋果 MAC OS 系統”及 Windows10 或以上作業系統的藍牙連接，但不排除舊有 Windows/ Mac OS 版本兼容可能性，請確認電腦具備支援進階音訊傳輸規範，藍牙版本或請升級您的作業系統。

潮濕時，請勿將 BEANS PRO 2 放入充電盒，否則可能導致 BEANS PRO 2 的電子零件或外殼嚴重損壞。BEANS PRO 2 充電盒不防水。

請將產品存放在乾燥處，遠離火、熱、濕氣和腐蝕性物質。

產品充滿電後，請從電源移除。長時間過度充電將縮短電池壽命。

BEANS PRO 2 接觸到水或汗水時，建議立刻清潔並擦乾。

請勿使用肥皂或清潔劑等粗糙的化學品擦洗產品。

請勿拆解、損壞產品或使其接觸水或火。不當使用產品將使保固失效。

如果電池膨脹或散發異味，請立即停止使用產品。


## NCC警語:

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

## 内容物




充电仓



耳机



Type-C 充电线



耳塞 × 6对



真皮吊带

## 挑选合适的耳塞

### i) 低音耳塞



增强低频，能进入耳道更深处，减少音场声波扩散路径上的阻碍，享有不同凡响的聆听体验与顶级舒适感。削弱部分齿音，声音更加温和厚重，增加音乐的可听性。

### ii) 平衡耳塞



超强密闭效果，能够服贴耳道的形状，提供强大的降噪效能，在隔绝外界干扰下，传递最真实、高还原的音乐。



## 總覽

- |                |                    |
|----------------|--------------------|
| <b>A</b> 磁性盖   | <b>F</b> 充电接口      |
| <b>B</b> 吊带扣   | <b>G</b> 麦克风       |
| <b>C</b> 充电插针  | <b>H</b> 触控介面      |
| <b>D</b> 电源指示灯 | <b>I</b> LED 指示灯   |
| <b>E</b> 耳塞    | <b>J</b> Type-C 輸入 |

## 降噪

轻触左侧 **H** 一次以切换：

1. 主动式降噪
2. 环境声音模式开启
3. 环境声音模式关闭



### 主动式降噪(ANC)

ANC 麥克風可分別分析並阻絕環境和耳內噪音。

### 环境声音模式

环境声音模式使用左右两侧内建的麦克风，让您即使戴着耳机也能听到环境声音。请注意周遭声音，以便安全地享受音乐。

# 充电

## 为耳机充电

✧ 白灯 ..... 正在充电

✧ 不亮 ..... 充电完毕




## 充电盒（未插电）

✧ ✧ ✧


闪烁 不亮 不亮 ..... 电量不足

亮起 不亮 亮起 ..... 正确放置

亮起 亮起 亮起 ..... 



## 为充电盒充电



电源  
(DC 5V/1A)

\*建议使用随附的充电线，以提供最佳充电体验


## 充电盒（正在充电）


✧ ✧ ✧

闪烁 不亮 不亮 ..... 


亮起 闪烁 不亮 ..... 

亮起 亮起 闪烁 ..... 


亮起 亮起 亮起 ..... 



## 佩戴





## 配对



彼此自动连接

1. 左  右  蓝灯闪烁 ..... 正在连接

2. 左  闪烁 / 1秒 ..... 已连接  
右  指示灯熄灭

将在两个耳机上听到警示音。

请确保设备的蓝牙功能已开启。

从蓝牙设备列表中查找  
“THECOOPIDEA BEANS PRO 2”，  
然后按“连接”。

成功配对后，耳机上的指示灯将熄灭。



# 控制



播放 / 暂停			
下一曲			2秒
上一曲			2秒
调高音量			
调低音量			
ANC / 环境声音 开启 / 关闭			
Siri/Google 助手			
接听来电			或
挂断通话			或
拒接来电			或
开机	将耳机从充电仓中取出		
关机	将耳机放回充电仓		
手动开机		及	
手动关机		及	
自动关机	空闲 10 分钟		

## 硬重设

关闭耳机，按住两个按钮 10 秒后放开，会听到「哔」声。关闭再开启耳机，将在 15 秒内彼此配对

● 轻触    长按

\*控制仅在两个耳机搭配使用时才适用

# 規格

型号	CP-TW08
颜色选择	樱花粉红、橄榄绿、纯粹黑
蓝牙版本	5.1
频率范围	20-20KHz
阻抗	32Ω
灵敏度	98dB ± 3 dB
驱动器大小	10mm
支持的编解码器	AAC, SBC
支持的配置文件	HFP, HSP, A2DP, AVRCP
播放时间	最长3小时 (ANC 开启), 4小时 (ANC 关闭)
OTG播放时间	最长21小时 (ANC 开启), 25小时 (ANC 关闭)
待机时间	100小时
充电时间	1小时 (充电仓), 1小时 (耳机)
电池容量	380mAh (充电仓), 40mAh (耳机)
充电仓尺寸	47 x 47 x 30mm (长x宽x高)
充电仓净重	31克
耳机尺寸	31 x 15 x 24mm (长x宽x高) (每只)
耳机净重	4克 (每只)
防水等级	IPX5 (耳机)
安全保护	短路、过量充电、过量放电

# 警告

请务必将耳塞放入充电仓内妥善保存。

请勿将耳塞放在高温或低温环境中, 以免电池电量耗尽。

避免长时间存放耳塞而不对其充电。

如果耳塞或充电仓污浊, 建议用蘸有清水的软布进行清洁。

本产品支援“苹果 MAC OS 系统”及 Windows 10 或以上作业系统的蓝牙连接, 但不排除旧有 Windows/ Mac OS 版本兼容可能性, 请确认电脑具备支援进阶音讯传输规范, 蓝牙版本或请升级您的作业系统。

如果充电仓潮湿, 请勿将 BEANS PRO 2 放入其中, 否则, 可能导致 BEANS PRO 2 的电子零件或外壳严重损坏。BEANS PRO 2 充电仓不防水。

请将本产品存放在干燥区域中。请远离易燃、发热、潮湿和腐蚀性材料。

产品充满电后, 请立即断开电源。长时间过量充电将缩短电池使用寿命。

BEANS PRO 2 接触水和汗水后, 建议立刻清洁并擦干 BEANS PRO 2。

请勿使用肥皂或清洁剂等粗糙化学品擦洗本产品。

请勿拆卸、损坏本产品或使其接触水或火。如因产品使用不当造成损坏, 恕不提供维修服务。

如果电池膨胀或发出异味, 请立即停止使用本品。

# **#THECOOPIDEA**

# **#BOLDTOBEFREE**

For other languages and  
soft copy of the manual,  
Scan:



Find out more at  
[www.thecoopidea.com](http://www.thecoopidea.com)

  **thecoopidea**