# thecoopidea




USER MANUAL

CP-TW05

V19-01


### Product overview




- A Multi-function button + LED light
- B Microphone Charging Interface
- TYPE-C input LED Light
  - **G** Magnetic Closure

Eartips

### Contents




## 1. Pre-use setup




Select and mount the Eartips to the earbudys. For the optimal experience, it is recommended to try each of the different Eartip sizes.

Note: Charge the earbuds for at least 1 hour before use.

#### 2. How to charge




2.1 Battery status




Off • Earbuds are fully charged

3. How to wear



2. Rotate slightly to get better fit and performance.

### 4. How to pair (Auto pairing)



- 2.Turn on bluetooth of your device
- 2.2 (first time) Search and connect to Earbuds

### 5. How to turn off/on Earbuds



#### Auto on/off

On - Pick up the earbuds from charging case Off - Place the earbuds back to charging case



#### Manual on/off

On - Hold both button for 2 sec Off - Hold both button for 4 sec


### 6. Call



### 7. Music



### 8. Full Controll List



### Specification

Frequency Response : 20 - 20KHz Bluetooth Version : 5.1 Bluetooth Range :10m Recharge Earbuds : 4 Times Battery : 400mAh Innut : 5V/1A (Type-C)

Case Dimensions : 71x36x33mm(LxWxH) Case Net Weight : 36q

Earbuds Net Weight : 4.5g (each) Waterproof Rating : IPX5 Stand by Time : 100hrs Playtime : Up to 5hrs

(Up to 20hrs On-The-Go)

Charging Time(Earbuds): 1hr (Charging Case): 1.5hrs(Type-C)









### Warning A

- Always store the earbuds in the charging case and safely protected.
- <sup>a</sup> Avoid storing the earbuds in hot or cold environments to prevent depletion of the battery capacity
- " Avoid storing the earbuds for extended periods of time without recharging them.
- " If the earbuds or the charging case become dirty, it is recommended to clean them with a soft cloth that has been dampened with clean water.
- <sup>85</sup> The OS version of mobile devices may affect performance of earbuds, it is recommended to update the OS of your mobile device to the latest version before use.
- " It is strongly recommended to clean and dry the earbuds properly when it has been exposed to water and sweat.
- " Don't put the earbuds into charging case while there is moist. Doing so can cause severe damage to the product. Earbuds charging case is not waterproof.
- "Remove from power source once the product is fully charged. Extended periods of over-charging will decrease battery life.

- Store the product in a dry area. Keep away from fire, heat, moist and erosive materials.
- " Do not use rough chemical such as soap or cleanser to scrub the product.
- Do not dissemble, damage, or expose the product to water or fire. Warranty will be voided by any misuse of the product.
- " If the battery is expanded or emits smell, stop using the product immediately.

# BE THE CULTURE. **BORN NIFTY.**

Find out more at www.thecoopidea.com

(f) (iii) the coopidea

Inspirations from New Zealand. Designed in Hong Kong. Produced in China, Copyright 2019 The Coop Idea Ltd.