


# Bullet Network Camera Installation Guide

V1.0.0

1.2.51.32.15633-000



**Optional**

1. Mounting the camera on a wall using a mounting bracket. A circular icon with 'T10' indicates the required screw size.
2. Accessing the camera's internal components. A 'RESET' button is shown on the left, and a 'Micro SD' slot is shown on the right with an upward arrow indicating the insertion direction.

**A**

1. Preparing the wall by marking the mounting hole. A circular icon with '5mm' indicates the hole diameter.
2. Drilling a 5mm hole into the wall.
3. Inserting the mounting bracket into the hole.
4. Mounting the camera onto the bracket.
5. Securing the camera with a screw.

**B**

1. Preparing the wall by marking the mounting hole.
2. Drilling a hole into the wall.
3. Inserting the mounting bracket into the hole.
4. Mounting the camera onto the bracket.
5. Securing the camera with a screw.
6. Final view of the camera mounted on the wall.

**a**

1. Stripping the outer jacket of the Ethernet cable.
2. Stripping the individual conductors.
3. Inserting the conductors into the RJ45 connector.
4. Crimping the conductors onto the connector.

**b** **Optional**

1. Stripping the outer jacket of the coaxial cable.
2. Stripping the inner insulation.
3. Inserting the conductors into the BNC connector.
4. Crimping the conductors onto the connector.
5. Final view of the prepared BNC connector.

