



Wi-Fi Bridge (BZ100)

Quick Start Guide

Compatible with Schlage Omnia
and Schlage eGO Smart Locks



Schlage Wi-Fi Bridge (BZ100)

Model :	Schlage Wi-Fi Bridge (BZ100)
Dimensions :	70mm x 70mm x 26mm
Network :	Wi-Fi 2.4GHz
IEEE standard :	802.11 b/g/n
Power interface :	Type-C USB
Power input :	5V/500mA

Light Status



When the Wi-Fi Bridge is powered on:

- Flashing Red/Blue light:
Stand-by mode - Ready to Pair
- Blue light: Normal mode
- Red light: Network failure

Warranty

The Schlage Wi-Fi Bridge (BZ100) has a one year warranty.

Our goods come with guarantees that cannot be excluded under the local consumer law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Disclaimer

We continuously optimise products as new technologies and features are developed. For this reason, we reserve the right to make alterations to the products without prior notice.



ALLEGION


www.allegion.com.au
www.allegion.co.nz

Pair Wi-Fi Bridge with Schlage Breeze App

- 1 Activate the app



- 2 Touch the "☰" icon on the top left of the screen




- 3 Select [Wi-Fi Bridge]




- 4 Press "+" sign



- 5 Select [Schlage Wi-Fi Bridge]



- 6 Plug in the Wi-Fi Bridge and power it on. Wait until the light flashes alternately red and blue, then press next



- 7 Add Wi-Fi Bridge



- 8 Select the network and input your Wi-Fi password



Note: If the device times out, please power off to reset and try again.