

6) FAQs

1. When you turn on the power switch, if only one blue LED light is twinkling, the battery will be run down soon. Time to recharge the device.
2. This product will automatically identify equipment that can be wirelessly charged. When no wireless devices are detected, it will power off after 5 minutes.
3. If the center point of the receiving terminal is 20mm out of alignment from the center point of the transmitting terminal, the machine will power off automatically.
4. If the transmitting terminal detects that the current load is over capacity, it will disconnect the connection automatically. The transmitting and receiving terminal will be kept in standby status automatically. To reset, turn off the receiving terminal and then restart.
5. When charging both wirelessly and with a cable, the device will detect when it is over its charging limit. When this happens, the transmitting terminal will disconnect the connection automatically. You must remove a device so that the current load can reach its rated current.
6. The battery will not get fully charged and the device may become damaged if you use a mismatched adapter.

7) Warranty

There is six month warranty for this product unless tampering is detected.

8) Packing List

- | | |
|------------------------|------|
| 1. Wireless power bank | 1PCS |
| 2. USB Cable | 1PCS |
| 3. Manual | 1PCS |

9) Specifications

- | | |
|--|--|
| 1. Wired Input: DC 5V==2A | 11. Display capacity: Displays electricity capacity with four blue LED lights, when wireless charging red light is on. |
| 2. USB Output: DC 5V==2.1A | 12. Charging type: charging with wire and wireless in the same time. |
| 3. Wireless Output: 5W 1000mA | 13. Sphere of application :Applies for all the products of Qi standard |
| 4. Charging frequency:100-200 KHZ | |
| 5. Wireless distance: 3to 8 mm | |
| 6. Efficiency: more than 75% | |
| 7. Product Size: 74*133*19 mm | |
| 8. Product Weight: 166.5g | |
| 9. Capacity: 8000 mAh | |
| 10. Carry type: Put it into travelling bag, laptop.bag, or car | |

Quantum Pro Wireless Power Bank Manual





Thank you for choosing Gorilla Gadgets' Wireless Power Bank. This instruction manual is provided to help you get the maximum enjoyment from your new product and to teach you how to take advantage of all its unique features. Before using this product please read the manual carefully.

1. General Information

This product is a well-designed portable aggregation battery with a high capacity transmitting wireless charging terminal in addition to a high-efficiency power bank. It can be used at home, outdoors, for travel, in the office, or in any other situations requiring wireless cellphone charging or charging with a micro USB connection.

2. Function Overview

- | | |
|----------------------------------|-------------------------|
| 1) Power bank | 4) Intelligent charging |
| 2) Wireless charging. | 5) Type-C input |
| 3) Rechargeable battery included | |

3. Introduction of button and indicator light

- | | |
|----------------------------|-----------------------------|
| 1) Micro USB Input | 6) Battery status Indicator |
| 2) Micro USB Output | 7) Wireless Charging Area |
| 3) Power Switch | 8) Non-slip Pad |
| 4) Wireless Charging Light | 9) USB Type C Input |
| 5) Power Light | |

4. Important Notes

- 1) Do not disassemble – this will void your warranty.
- 2) This product is not waterproof. Protect it from water and wet environments.
- 3) Do not store it in a hot environment
- 4) Use a suitable adapter to connect with the wireless transmitting terminal
- 5) Do not puncture it or dispose of it into fire or water
- 6) Stop use immediately if the battery starts to bulge, leak, or smell
- 7) This product should be charged once every month at least when you do not use it for a long period
- 8) Long press the power switch for three seconds to turn off the power when you are not using the wireless charger
- 9) Remove the protective layer before recharging
- 10) Do not attempt to use the wireless charging feature while you are recharging this device.

5. Operations

1) Turn on/off: Light press the power switch to turn on the device. The blue lights indicate the power is on. Long press the power switch three seconds to turn on/turn off the wireless charging function. The red light will go off.

2) Charging the Charger: Insert a USB cable into the Micro 5 PIN jack. The other end should be connected to a power source adapted for USB output. You will see blue LED light s twinkling while the device is charging and al the blue LED lights will stay on without blinking when it is fully charged.

3) Charging for Other Electronic Products:

Wired Charging: Turn on the power switch. The blue indicators lights show the device is ready to begin charging. Insert the USB jack into the power bank and the other end into the input jack for the device that needs recharging.

Wireless Charging: Turn on the wireless charger using the On/Off Switch. The red indicator light shows it is on . Place your mobile phone on it and look for your phone's indicator that it is being charged.