


DREAM MASTER QUICK START



GETTING STARTED

Congratulations!

You now own one of the most advanced personal audio/visual stimulation devices available.

We realise you are eager to get started and always recommend that you read the full Dream Master manual if you have the time, which lists all the advanced functionality.

At the very least, please read the safety statements before continuing. Specifically - DO NOT USE without consulting your physician if you have photo-induced epilepsy, have psychosis or brain damage and/or you are taking medication for same, are pregnant or a minor. Do not use while driving a car or operating machinery.

The Deepak Chopra Dream Master manual is a great place for answers to questions.

For additional support go to:

[www.DeepakChopraDreamWeaver.com/
Pages/MasterSupport](http://www.DeepakChopraDreamWeaver.com/Pages/MasterSupport)

Thank you from Deepak and all here at Deepak Chopra Dream Weaver.

We hope you enjoy using your Dream Master!

Quick start instructions

1. Charge the Dream Master with the included USB cable by plugging the mini-USB end into your Dream Master and the other end into the USB outlet of your computer or phone charger. This should take several hours or less.

2. Insert the micro-SD card as shown. You will feel a slight spring pressure before it locks into place.

To remove card ensure your Dream Master is turned off then gently press the micro-SD card so that it unlatches and springs out sufficiently to grasp.

3. Connect Light Goggles.

4. Connect supplied Earbuds or your own Headphones.

5. Press and hold the Power button for two seconds to turn Dream Master on.

6. Navigate using the Control Pad to the "Sessions" icon and push the "Select" button.

7. Navigate folders and sessions that you wish to play using the Control Pad Up, Down & Select.

8. Push Control Pad Select button to start playing the session.

9. Adjust Earbuds/Headphones volume and Light Goggles brightness level to suit.