

INSTALLATION INSTRUCTIONS DONUT 120H

INSTALLATION INSTRUCTIONS DONUT 120H

INSTALLATION INSTRUCTIONS DISCOVERY 1200



SCREWS

BEARINGS

RISER



WRENCHS




WASHERS



END CAP




The parts in the orange wire frame have been installed on the tread assembly.







Install Cloudwheel 120H to the relevant position on the motor stator, align the screw holes, and tighten the screws.



If Cloudwheel 120H rubbing the board surface when you turn the corner,please add the risers to truck.









CLOUDWHEELS



SCREWS



BEARINGS

RISER






WRENCHS




WASHERS







Please remove the hub motor screws. then remove the original tread.







when you turn the corner,please add the risers to truck.



the sleeves must be installed.







CLOUDWHEELS



SCREWS



BEARINGS

RISER





WRENCHS



WASHERS







Please remove the hub motor screws. then remove the original tread.



Install Cloudwheel 120H to the relevant position on the motor stator, align the screw holes, and tiahten the screws.



If Cloudwheel 120H rubbing the board surface when you turn the corner,please add the risers to truck.









WHAT'S INSIDE

CLOUDWHEELS



WRENCHS

WASHERS

SCREWS




BEARINGS






INSTALLATION INSTRUCTIONS DONUT 120H



Please remove the hub motor screws. then remove the original tread.


Install Cloudwheel 120H to the relevant position on the motor stator, align the screw holes, and tighten the screws.

INSTALLATION INSTRUCTIONS DONUT 120H




when you turn the corner,please add the risers to truck.

INSTALLATION INSTRUCTIONS DISCOVERY 1200





⊠ service@icloudwheel.com





WHAT'S INSIDE

CLOUDWHEELS



WRENCHS

WASHERS

SCREWS




BEARINGS


RISER



INSTALLATION INSTRUCTIONS DONUT 120H




Please remove the hub motor screws. then remove the original tread.



tighten the screws.

INSTALLATION INSTRUCTIONS DONUT 120H



If Cloudwheel 120H rubbing the board surface when you turn the corner,please add the risers to truck.

INSTALLATION INSTRUCTIONS DISCOVERY 1200

