HOW TO REPLACE THE RECHARGEABLE BATTERY

ARCE

argeecorp.com

- Remove all 6 screws
- Remove cover and battery Keep gasket for water-tight seal
- Replace ONLY with Ni-MH Rechargeable AAA battery
- Replace cover and gasket Tighten screws

PROTECT YOUR WARRANTY!

** TIGHTEN ALL 6 SCREWS **



CAUTION: Do not over-tighten screws

WARRANTY VOID IF WATER ENTERS CUBE Turn over for instructions to activate the solar light.

TO ACTIVATE THE SOLAR LIGHT REMOVE THE BATTERY PULL-TAB

Your Let's Edge It!® Solar Cubes have been shipped with protectors to keep the battery fresh. You need to remove them prior to use from the underside of each Solar Cube..

● Loosen only the first 2 screws Do not remove

Remove tab by pulling out completely Be careful not to dislodge the battery

PROTECT YOUR WARRANTY!

** TIGHTEN ALL 6 SCREWS **

WARRANTY VOID IF WATER ENTERS CUBE

Note: Solar lights may come in a discharged condition. If so, several days in the sun will bring them up to full charge.

rged will *CAI*



CAUTION: Do not over-tighten screws

Turn over for instructions to replace the battery.