


AXWK WIRELESS KEYPAD IDENTIFICATION

for Wireless Keypad Versions 1, 2 and 3


Version 1: Distinguishing Feature

The SEND button will be white with black letters



Version 2: Distinguishing Feature

1. The SEND button will be green with black letters
2. The keypad will beep two times when the C batteries are put in
 - Remove one battery from the keypad
 - Wait 10 seconds insert the battery (it will beep 2 or 3 times, pause for 5 seconds, beep twice and go into sleep mode)
 - If it initially beeps 2 times before the pause it is a V2 keypad



Version 3: Distinguishing Feature

1. The SEND button will be green with black letters
2. The keypad will beep three times when the C batteries are put in
 - Remove one battery from the keypad
 - Wait 10 seconds insert the battery (it will beep 2 or 3 times, pause for 5 seconds, beep twice and go into sleep mode)
 - If it initially beeps 3 times before the pause it is a V3 keypad

