



TOK TOK WILL AUTOMATICALLY TALK BACK!

- Press the (M) Mode Button until you hear 1 beep and see TOK TOK'S face glow.
- **2** Talk to TOK TOK and it will repeat what you say.
- Swipe TOK TOK's face and hear its voice change.





Meet TOK TOK, your wacky robot pal that morphs and changes your voice! Spin his face to choose from 3 different moods - and a voice to match each one!

GET GIGGLY & CREATE FUNNY MESSAGES WITH YOUR FRIENDS!

TOK TOK records and repeats your audio with the press of a button.

Use Echo Mode and watch TOK TOK listen to everything you say and repeat it back to you in 3 different voices!

Give him a good shake to unlock his secret sounds!

BRIGHT | RECORD / ECHO | MOTION | LEDs | & PLAY / MODE | SENSOR





The fun is here! Before we begin, let's get to know TOK TOK!




Swipe face left or right to morph voice

RecordPlay

■ Stop



- Press the (M) Mode Button until you hear 2 beeps and see TOK TOK'S face glow.
- Press and hold the (•) Record Button. Start recording after you hear the beep. Release the button when you've finished and hear TOK TOK repeat it back to you.
- Press the (▶) Play Button to play your message again. Press the (■) Stop Button to stop.
- Swipe TOK TOK'S face to change its voice. It will replay the recorded message automatically.



MOTION SENSOR

MOVE TOK TOK AROUND TO HEAR SECRET SOUNDS!

SHAKE SHAKE



DOWN

SHAKE IT, JIGGLE IT, TILT IT, WIGGLE IT!

ON ITS BACK



BATTERY

KEEP YOUR TOK TOK POWERED UP!

