


LIV-012-321-0001 1LA

**FLIPPER**  
Two Device Universal



# Code List North America

ABEX	0401
ACER	3221
ADMIRAL	1441,1661,2731
ADVENT	0631,2321,3211
ADVENTURA	0151
AIKO	1011
AIWA	0651,0931
AKAI	2141,2741
ALLERON	1711
AMARK	1441
AMTRON	2191
ANAM NATIONAL	0271,2151
AOC	0001,0011,0251,0391, 0611,0891,2701,2901
APEX	0431,2471,2691,2911
ARCHER	1441
ASPECT	2051
AUDIOVOX	2191
AURORA	3051
AXION	2191
BANG & OLUFSEN	1591
BELCOR	0001,2901
BELL & HOWELL	1661,2851, 2871
BENO	1761,2221
BRADFORD	2191
BROKSONIC	0211,0371, 0851,1631
BROKWOOD	0001,2901
CANDLE	0001,0151, 0961,2901
CAPEHART	0391
CELEBRITY	2741
CELERA	2691
CENTRIOS	1111
CENTURION	2901
CETOMER	2961
CETRONIC	2191
CHANGHONG	2691
CHIMEI	3051
CITIZEN	0001,0371,0961, 1011,1311,1381,1661, 2141,2191,2691,2901
CLAIRTONE	0011
CLASSIC	2191,2691
CLP	0061
CLP CLASSIC	0001,0041, 2321,2901
COBY	2511,2551,2521, 2531,2541,3271
COLOR VOICE	1841
COLORTYME	0001,1841,2901
CONCERTO	0001,2901
CONCIERGE	0991
CONTEC	0011,1911,2191
CORNEA	2901
CRAIG	2191
CROSLEY	2321
CROWN	2191
CTX	1441
CURTIS MATHES	0001,0261, 1191,1311,1561,1661,2141, 2691,2851,2871,2901
CXC	2191
DAEWOO	0001,0221,0251, 0591,0721,0831,0971,1011,

DAEWOO	1081,1231,1251, 1561,1841,2181,2191, 1501,2701,2901
DAYTRON	0001,2901
DELL	0981,2321,2901
DIAMOND VISION	1211,2001
DIGISTAR	0381,0871,2321, 2701
DIMENSIA	2851
DISNEY	1101
DISTAR	3181
DUKANE	0401,2051
DUMONT	0001,0991,2901
DURABRAND	0371,0861,1381, 2291,2471
DYNASTY	2191
DYNEX	0371,2891,3101,3121
ELECTROBAND	0011,2741
ELECTROHOME	0001,1921, 2151,2901
ELEKTRA	1661
ELITE VIDEO	0901
EMERSON	0001,0021,0031, 0041,0271,0281,0291,0371, 0441,0451,0691,0701,0731, 0851,0931,1251,1341,1381, 1451,1461,1561,1631,1681, 1701,1711,1801,1931,2171, 2191,2871,2901
ENVISION	0001,0071,2901
FISHER	1581,1911,2871
FUJITSU	0901,1711
FUNAI	0701,0931,1381, 1711,2191
FUTURETEC	2191
GATEWAY	0501
GE	0001,0041,0051,0141, 0361,0791,1001,1921, 0261,1951,2151,2851, 2901
GIBRALTER	0001,0991,2901
GOLDSTAR	0001,0251,0611, 0761,0931,0991, 1501,1911,2701,2901
GRUNDY	1711,2191
GUESTVISION	2321
HAIER	0861,2221,2471
HALLMARK	0001,2901
HARVARD	2191
HISENSE	2211,2321,2471
HITACHI	0001,0401,0841, 0931,0941,1341,1661,1721, 1801,1911,2051,2901,3261
ILO	1141,1971,2481
IMA	2191
INFINITY	2321
INITIAL	2481
INSIGNIA	0371,0701,0871, 1241,1381,2241,2271, 2321,2471,2891,2921
INTEGRA	1841
INTEQ	0991
ISymphony	3031
IANBIL	0151
IHL	2321
ICB	2741

IENSEN	0001,2271,2901
IVC	0311,0481,0771, 0901,0941,1801,1911
KAWASHO	0001,2741,2901
KAYPANI	0391
KFC	2191
KENWOOD	0001,2901
KLH	2691
KLOSS NOVABEAM	0151,1021
KONKA	0751,1241,1671, 2121,2191,2241,2371
KTV	0011,1491,1681,2191
KURAZAI	1661
KWORLD	2931
LASONIC	1211
LG	0001,0251,0611,0761, 0931,0991,1501,1911, 2701,2901,3001,3021, 3071,3171,3231
LODGENET	1661,2091,2851
LUCE	2501
LUXMAN	0001,2901
LXI	0001,0261,0931,1001, 1311,2321,2691,2851, 2871,2901
MAGNASONIC	1711
MAGNAVOX	1151,0001,0321, 0701,0961,1021, 1801,2321,2731,2901
MAJESTIC	1661,2851
MARANTZ	0001,1841, 2321,2901
MEDION	1101,1141,2351
MEGATRON	0001,2051,2901
MEI	0011
MEMOREX	0001,0371,1631, 1661,1711,2851,2871,2901
MGA	0001,0251,1581,1711, 1801,1911,1921,2791,2901
MIDLAND	0051,0261
MINUTZ	0991,1001,2851, 1951
MITSUBISHI	0001,0251,1581, 1711,1801,1921, 2701,2901
MONIVISION	0491
MONTGOMERY WARD	1661, 2851
MOTEVA	2871
MOTOROLA	1441,2151
MTC	0001,0011,0251, 1311,2141,2691,2701,2901
MULTITECH	2191
MULTIVISION	0081
MYRON & DAVIS	2101
NAD	0001,0401, 1311,2691,2901
NEC	0001,0251,0341,1801, 1841,2151,2701,2901
NET TV	0501
NEXXTECH	0871,1201
NIKEI	2191
NIKKO	0001,1011,2901
NORCENT	0511,2181,2471
NTC	1011
OLEVIA	2771,2781

OLEVIA	2791,2901,2971
ONCOMMAND	2321
ONKING	2191
ONWA	2191
OPTIMUS	0401,0951,2711
OPTOMA	2441,3091
OPTONICA	0341,1441
ORION	0281,0371,0991
PANASONIC	0051,0951,1491, 2151,2321,2711, 2801,3281,3301
PHILCO	0001,0251,0321, 0961,1021,1801,2151, 2321,2701,2901,2941
PHILIPS	0321,1151,0541,0701, 0791,0961,1021,1381, 1601,1801,2151,2901, 3091,3111,3131,3291
PHILIPS-MAGNAVOX	2321,2731
PILOT	0001,2901
PIONEER	0001,0401,1341, 1511,1841,2901
PIVA	2411
POLAROID	2421,2271, 2311,2321
PROSCAN	0261,1001
PROTON	2061,2301,2851, 0001,0391,0641, 1911,2231,2901
PROVIEW	2421
PULSAR	0001,0991,2901
PYLE	3251
QUASAR	0051,0951,1491, 2151,2321,2711
RADIO SHACK	0001,0341, 0931,1001,1701,1911, 2191,2711,2851,2871,2901
RCA	0001,2777,0051,0091, 0251,0261,0361,0551,0891, 1001,1131,1331,1341,1561, 1921,2061,2151,2251,2301, 2581,2701,2851,2901,2951
REALISTIC	0001,0341,0931, 1001,1701,1911,2191, 2711,2851,2871,2901
RHAPSODY	0011
RUNCO	0991,1771,1841
SAMPO	0001,0391, 0501,1911,2901
SAMSUNG	0001,0101,0251, 0261,0331,0531,0571,0711, 1191,1311,1501,1911,2071, 2141,2691,2701,2721,2901, 3241
SAMTRON	2141
SANSUI	0371,1631
SANTECA	0171
SANYO	0001,0801,1051,1581, 1911,2871,2881,2901, 2981,2991,3041
SCOTCH	0001,2901
SCOTT	0001,0021,0281, 1711,2191,2901
SEIKI	0131
SELECTRON	2321,2471,2501
SHARP	0001,0341,0461,0691

**SHARP** 1441, 2031, 2261, 2731, 2901, 3141, 3151, 3161  
**SHOGUN** 0001  
**SIGNATURE** 1661, 2171, 2951  
**SIGNET** 2811, 2821, 2861  
**SIMPSON** 0961  
**SONIC** 0011  
**SONY** 1071, 1641, 1731, 2161, 2741  
**SOUNDESIGN** 0001, 0961, 1711, 2191, 2901  
**SPECTRAVISION** 0791  
**SQUAREVIEW** 1381  
**SSS** 0001, 2191, 2901  
**STAR SIGHT** 0061  
**STARLITE** 2191  
**SUPERSCAN** 0701, 2021, 2731  
**SUPERSONIC** 0241  
**SUPRA** 0001, 1991, 2901  
**SUPREMACY** 0151  
**SUPREME** 2741  
**SYA** 2471  
**SYLVANIA** 0001, 0321, 0371, 0701, 0931, 0961, 1021, 1381, 1601, 1801, 2321, 2761, 2901  
**SYMPHONIC** 0021, 0701, 0931, 1381, 2191  
**SYNTAX** 2901  
**TANDY** 1441  
**TATUNG** 1141, 2151, 2221  
**TECHNICS** 0051  
**TECHWOOD** 0001, 0051, 2901  
**TEKNIKA** 0001, 0151, 0251, 0961, 1011, 1311, 1661, 1711, 1911, 2141, 2191, 2691, 2701, 2711, 2851, 2901  
**TELECAPTION** 0821  
**TELERENT** 1661, 2851  
**TERA** 0001, 0641, 2901  
**TEVION** 1141  
**TMK** 0001, 2901  
**TOSHIBA** 0211, 0231, 0341, 0821, 1121, 1191, 1311, 1801, 1841, 1911, 2141, 2691, 2711, 2871  
**TRUTECH** 2461  
**UNIVERSAL** 0791, 1951  
**VICTOR** 0941  
**VIDTECH** 0001, 0251, 2701, 2901  
**VIEWSONIC** 0401, 0501  
**VIKING** 0151  
**VIORE** 2831, 2841  
**VIZIO** 2221, 2901  
**WARDS** 0001, 0021, 0251, 0321, 0341, 0791, 0961, 1021, 1321, 1661, 1711, 1951, 2321, 2701, 2851, 2901  
**WESTINGHOUSE** 0111, 2281, 3191, 3201  
**WHITE WESTINGHOUSE** 0601, 0931, 1081, 1501, 1561  
**YAMAHA** 0001, 0251, 2701, 2711, 2901  
**ZENITH** 0001, 0061, 0131, 2321, 2731, 0691, 0931, 0991

**ZENITH** 1191, 1251, 1631, 1661, 1771, 2051, 2171, 2291, 1011, 1081, 0371, 2901  
**100MG** 1283  
**ACCESSHD** 1273  
**ADB** 1243  
**AMINO** 1223, 1233  
**AMPLICA** 0103  
**BELLEXPRESSVU** 0073, 0173, 0343  
**CHANNEL MASTER** 0283, 0393, 0483, 0573, 0653  
**CHAPPARAL** 0573, 0653  
**CHEYENNE** 0653  
**DIGITALSTREAM** 1203  
**DIRECTV** 0983  
**DISH NETWORK** 0073, 0173, 0343, 0403, 0493, 0493, 0603, 0783, 1003, 1013, 1023, 1033, 1043, 1053, 1063, 1303, 1313  
**DISHPRO** 0073, 0403, 0493, 0603  
**DRAKE** 0023, 0293, 0733  
**DXANTENNA** 0383, 0753  
**ECHOSPHERE** 0173  
**ECHOSTAR** 0073, 0173, 0343, 0403, 0493, 0603, 0783  
**ENTONE** 1253  
**EXPRESSVU** 0073, 0173, 0343  
**FORTECSTAR** 0083, 0183, 0263, 0373, 0463, 0473  
**FUJITSU** 0673, 0763  
**GE** 0643, 0723, 0793, 0873, 1083  
**GEMINI** 0123  
**GENERAL INSTRUMENT (GI)** 0013, 0093, 0193, 0453, 0633, 0833, 0893, 0953, 0963  
**GLOBECAST** 0003  
**HITACHI** 0303, 0443, 0623  
**HNS** 1153  
**HUGHES NETWORK** 0303, 0443, 0563, 0703, 1153  
**INSIGNIA** 0253  
**IVC** 0173, 0783  
**KENWOOD** 0413  
**LG** 1153  
**LUXOR** 0503  
**MACOM** 0613  
**MAGNAVOX** 0203, 0533, 0783, Magnavox Models 100MG9  
**1283**  
**MITSUBISHI** 0303, 0443, 0623, 1153  
**MOTOROLA** 0453  
**NORSTAT** 0683  
**PACE** 0053, 0133  
**PANASONIC** 0213, 0223  
**PANSAT** 0033, 0883  
**PHILCO** 1283  
**PHILIPS** 0203, 0303, 0443, 0533, 0623, 0703, 0783, 1153  
**PHILIPS-MAGNAVOX** 0203,

**PHILIPS-MAGNAVOX** 0533, 0783  
**PRIMESTAR** 0633, 1263  
**PROSAT** 0813  
**PROSCAN** 0643, 0723, 0873, 1083  
**RCA** 0363, 0543, 0643, 0723, 0793, 0873, 1083  
**REALISTIC** 0273, 0843  
**SAMSUNG** 0233, 0853, 1113, 1123, 1143, 1213  
**SIERRA III III** 0653  
**SKY NETWORK** 0053, 0133  
**SONY** 0113, 0553, 0773  
**STAR SIGHT** 0863  
**STARTRAK** 0423  
**STARCHOICE** 0633  
**STS** 0383, 0583, 0663  
**SUPER GUIDE** 0513  
**TELUS** 1293  
**TIVAX** 1273  
**TOSHIBA** 0063, 0143, 0303, 0443, 0623, 0713, 1133, 1153  
**ULTIMATE TV** 0553, 0873  
**UNIDEN** 0693, 0823, 0863  
**VIDEO CIPHER II** 0023  
**WEB TV** 0113, 0783  
**ZENITH** 0023, 0123, 0153, 0253, 0293, 0313, 0733, 1173  
**ZTE** 1323

**ABC** 0004, 0074, 0134, 0464, 0594  
**ADELPHIA** 0664, 0714, 0724  
**ALLEGRO** 0054, 0114  
**AMERICAST** 0254, 0894  
**ANTRONIX** 0264, 0334  
**ARCHER** 0264, 0334, 0474  
**ARTEC** 0854  
**AT&T** 0674, 0724  
**BELL SOUTH** 0254  
**BRIGHT HOUSE** 0714  
**CABLETENNA** 0264  
**CABLEVIEW** 0264  
**CABLEVISION** 0654, 0714, 0724  
**CENTURY** 0474  
**CHANNEL MASTER** 0834  
**CHARTER** 0894  
**CHARTER** 0664, 0684, 0714, 0724  
**CHARTER COMMUNICATIONS** 0874  
**CHARTER DIGITAL** 0864  
**CISCO** 1013  
**CITIZEN** 0474  
**COGECO** 0724  
**COMCAST** 0684, 0714, 0724, 1014  
**COMTRONICS** 0014, 0084  
**CONTEC** 0144  
**COSHIP** 0844  
**COX** 0914, 0934, 0944  
**COX DIGITAL CABLE** 0714, 0724

**DIGITAL MUSIC EXPRESS** 0044  
**EASTERN** 0214  
**EVERQUEST** 0014  
**GARRARD** 0474  
**GC ELECTRONICS** 0334  
**GE** 0384, 0794  
**GEMINI** 0204, 0344  
**GENERAL INSTRUMENT (GI)** 0004, 0044, 0074, 0464, 0594, 0634, 0724  
**GOODMIND** 0794  
**HAMLIN** 0464  
**HITACHI** 0594  
**ILICO** 0714  
**INSIGHT** 0884, 0904  
**IASCO** 0474  
**IERROLD** 0004, 0074, 0194, 0324, 0464, 0594  
**LASONIC** 0804  
**MAGNAVOX** 0094  
**MEDIACOM** 0914  
**MEMOREX** 0624  
**MICROGEM** 0814  
**MOTOROLA** 0004, 0074, 0194, 0464, 0594, 0634, 0674, 0684, 0724  
**MOVIE TIME** 0224  
**NSC** 0224  
**OAK** 0144, 0354  
**PACE** 0714, 1014  
**PANASONIC** 0304, 0394  
**PARAGON** 0624  
**PHILIPS** 0084, 0094, 0344, 0424, 0474, 0554  
**PHILIPS-MAGNAVOX** 0064, 0104  
**PIONEER** 0024, 0274, 0614, 0714  
**PULSAR** 0624  
**RADIO SHACK** 0064, 0104, 0114  
**RCA** 0244, 0394, 0474  
**REALISTIC** 0334  
**REGENCY** 0214  
**REMBRANDT** 0594  
**ROGERS** 0714, 0924  
**RUNCO** 0624  
**SAMSUNG** 0014, 0024, 0714  
**SCIENTIFIC ATLANTA** 0714  
**SCIENTIFIC ATLANTA/CISCO** 0944, 0954, 0964, 0974, 0984, 0994  
**SCIENTIFIC ATLANTA** 0124, 0134, 0164, 0234, 0724, 1004  
**SHAW** 0014  
**SIGNAL** 0014  
**SIGNATURE** 0594  
**SKARDIN** 0824  
**SL MARX** 0014  
**SPRUCER** 0394  
**STANDARD** 0364  
**STAR SIGHT** 0244  
**STARTRAK** 0184  
**STARCOM** 0464  
**STARGATE** 0014  
**TANDY** 0434  
**TELEVIEW** 0014  
**TEXSCAN** 0364

**TIME WARNER** 0713, 0723  
**TIVO** 0794, 0754, 0754, 0774  
**TOCOM** 0004, 0504, 0634  
**TOSHIBA** 0624  
**TV86** 0224  
**UNIKA** 0264, 0334, 0474  
**UNITED CABLE** 0464  
**UNIVERSAL** 0054, 0264, 0334, 0474, 0564, 0684, 0724, 0784  
**VERIZON** 0684, 0724, 0784  
**VIDEOTECH** 0454  
**VIDEOTRON** 0714  
**VIDEOWAY** 0034  
**VIEWSTAR** 0084, 0094, 0224, 0434  
**VOOM** 1024  
**ZENITH** 0114, 0474, 0524, 0584, 0624, 0644  
**ZENITH NETWORK** 0254  
**ZENTECH** 0824