




THE AUTOMOTIVE LIGHTING BENCHMARK




INSTALLATION GUIDE

XB BALLAST (AMP)



WARNING: By reading this document, I agree it is only to be used as an educational guide. Morimoto Lighting makes no guarantee on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below to your own application, professional installation is recommended.

STANDARD PARTS




2X XB BALLAST COMPUTER



2X XB AMP IGNITER

OPTIONAL PARTS




2X CARBON FIBER BRACKET

TABLE OF CONTENTS

SYSTEM DIAGRAM	P. 2
BALLAST ASSEMBLY	P. 3

SYSTEM DIAGRAM



ASSEMBLY



DO NOT IGNITE UNTIL FULLY CONNECTED!



DO NOT CUT!

STEP BY STEP

1

Do not force connection!

2

3

12V Input (9006 Female)

4

Listen for click of connectors to ensure fully seated!

5

Recommended mounting:

Do not mount ballast with connectors aimed upward!

-END-