NW.FLEXTAIL.COM

# The Guide of MAX VACUUM PUMP

WWEIERIA

NN.FLE

Kall.co.


FLEXTAIL

-MP01NR01-

# Catalogue <sup>©</sup>

Catalogue	
ELEKTAN KANLO	
Catalogue ·	14
Function demonstration ·	15
Nozzle ·····	15
Parameter Information	16
Operation instructions	17-19
Product introduction	20-26
Guarantee card ·····	27

### **Function demonstration**




Exclusive nozzle for vacuum bags

# Parameter Information


Weight	335g±10
Dimension	62.5*75.5*117mm
Deflation pressure	10kPa
Compression ratio	90%
Rated power	72W
Rated current	6A
Endurance	25min
Battery capacity	2500mAh
Package content	MAX VACUUM PUMP/ Type-C cable /Manual / Storage bag / Nozzles
Certification	CE , FCC , RoHS

## **Operation instructions**




Switch with function of preventing mistakenly touching

To prevent unintended activation, the switch adopts an anti-mistakenly touching design, please read the following instructions carefully before use.



First press the unlock button.



Then toggle the switch button.

#### Deflate the airbed.





Line up with the air valve of the airbed.





Connect the airbed and turn on the pump.


#### Vacuum bag





Connect the vacuum bag with the special nozzle.





Line up with the air valve of the vacuum bag and turn on the pump.

#### Power indicator schematic:

#### Low battery indication

0%-10%

When the red light is on, it means the pump need to be charged.

#### Charging indication

0%-99%

100%





















<43°C (110F°) >–17°C (0F°)

# Product introduction [English ] MAX VACUUM PUMP The vacuum pump for self inflating mattress

#### Product

(As shown in the drawing figures)

- Operation (As shown in the drawing figures)
- Storage and transportation (As shown in the drawing figures)
- Care and maintenance
   (As shown in the drawing figures)

#### **Troubshooting**

If the product does not work:

- Please check if there is water or other liquid on the surface.
- · Check whether the fan blade is stuck.
- Press the switch repeatedly.
- Other questions? Please contact FLEXTAIL Technology agents or contact us: service@flextailgear.com.

#### Reserve piece

There are no user-replacement parts for this product other than the nozzles and charging cable.

#### Warnings

- Do not use it for more than 10 minutes.
- Do not put it under the water for a long time.
- Keep the inflation port or the deflation port clean.
   Do not put your finger into the inflation port or
- deflation port when the pump is working.
   Do not watch the inflation port or deflation port
- · when the pump is working.
- Children under the age of 12 need to have adults' supervision when using the pump.
   Please check whether the air pump is functioning
- properly before use.

FLEXTAILGEAR shall not be liable for any direct, indirect, incidental or other damages arising out of or caused by the use of the products. Users are responsible for their own actions and all the consequences that result from these actions.

#### Warranty terms

For the defects in material and workmanship of the product, the original retail purchaser of this product will be provided a warranty service for one year based on purchase data by FLEXTAILGEAR. If the Buyer discovers a covered defect, the buyer should return the product to the place of purchase. If this is not available, please return the product to the address specified by us. We will repair or replace the modified product at our discretion following the warranty terms.

We assume the above responsibilities in accordance with the essential guarantee terms during the warranty period. After the expiration of the warranty, the service will no longer be provided. We reserve the right to require proof of purchase for all warranty applications.

#### Warranties Exclusions

We do not warranty products against normal wear and tear, unauthorized modifications or]alternations, improper use, improper maintenance, accident, misuse, negligence, damage, or if the Product is used for a purpose for which it was not designed. This warranty gives you specific rights, and you may also have other rights which vary from state to state. Except for expressly stated in this warranty, we shall not be liable for direct, indirect, incidental, or other types of damages arising out of, or resulting from the use of Product. This warranty is in lieu of all other warranties, expressed or implied, including, but not

limited to,implied warranties of merchantability or fitness for a particular purpose(some states do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on the duration of an implied warranty, so the above exclusions may not apply to you.)

NAMELEK ALL. COM

NAMELEK ALL. COM

NAMELEK ALL. COM

NAMELEK ALL. COM

NAMELEK ALL. COM