

CAMTREE Hunt Camera Cage (CH-BMUM-C)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Camera Plate with
shoulder pad



Top Plate



Side Bracket



Top Handle



2x 200mm Female Aluminum Rods



Dovetail plate



15mm Rod Adapter



2x 300mm Female Aluminum Rods



Rosette Arm

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ Hunt Camera Cage Setup

- Attach the dovetail plate to the tripod plate (Not Included) and secure them together using a screwdriver (Not Included). Next, mount the plate on your tripod head (Not Included). Tighten it well to secure it.



NOTE: Firstly Secure the camera with Base plate and then attach the side Bracket and top plate.

- Attach the shoulder pad to the camera plate and tighten it well using a screwdriver (Not Included).



- Remove the two side screws on the camera plate and attach the lens support side bracket. Tighten well to secure it.



- Attach the camera plate with the lens support side bracket and insert two 200mm rods into the 15mm rod adapter. Tighten the knob to secure them.



- Attach the top handle and tighten the knob properly.



- Mount the camera plate on the dovetail plate and tighten the knob securely.



- Insert two 300mm rods into the 15mm rod adapter and tighten the side knob.



- If required, you can mount Arri Standard Rosette Arm to use a handgrip.



YOUR CAMTREE HUNT CAMERA ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.