CAMTREE HUNT

Camera Cage With Handle & Baseplate

(CH-A63-C)

INSTRUCTION MANUAL



INTRODUCTION

In order to get the best out of your A6300, Camtree hunt proudly unveils its peculiar A6300 Camera cage to give your every shot a more refined & professional feel. The robust cage not only covers your camera for multiple mounting choices but also keeps it protected. This cage provides easy access to the battery allowing you to replace it without removing the camera from the cage. The sturdy handle & base plate have 15mm threads for mounting accessories and expanding the rig, locking clamp prevents accidental cable disconnects. The well-engineered base plate lets you easily switch your camera from tripod to handheld and can move back and front easily. The multi-functional Rod support provides a wide variety of options for mounting your other accessories.

IN THE BOX

Please inspect the contents of your shipped package to ensure you have received all that is pictured and listed below.



ASSEMBLING YOUR HUNT CAMERA CAGE WITH HANDLE & BASEPLATE

• Attach the quick release plate of your tripod head with dovetail plate and tighten it with the help of screw driver. Now mount the dovetail plate on fluid head and secure it properly.






• Slide-in the rod adapter with cage into the dovetail plate and lock it with the help of knob as shown.





• Insert 200mm female threaded rods into the rod adapter and tighten the knob.





• Loosen the knob and remove the camera cage as shown.





• Insert the camera into the cage and tighten it with the help of screw-driver. Then slide it into the rod adapter and tighten with knob to secure.





• Now slide the handle into the cage & tighten the knob.





YOUR CAMTREE HUNT CAMERA CAGE WITH HANDLE & BASEPLATE ALL DRESSED UP AND GOOD TO GO



(SHOWN WITH OPTIONAL ACCESSORIES)

WARRANTY

We offer a one year warranty for our products from the date of purchase.

We will repair or replace your product, free of charge, in the event of a defect in materials or craftsmanship obtained during normal use or handling based on the user manual. Please note that we will not cover any shipping costs for returning the product to us. If any VAT or import duties are applied to the return, we will also charge these costs to the customer.

The warranty does not include, by the way of example, damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

We are not liable for incidental or consequential damages resulting from the use of the unit or occurring due to any breach of this warranty.

Replacement parts of the product will be provided at nominal cost (covering the cost price of the replacement parts only) to the customers after the Warranty Period has expired. We will cover the complete cost of sending replacement parts within the warranty period. After that, nominal cost of the product & Actual shipping cost will be charged.

Do not send the unit to us without first getting a response and getting the approval to send back the item.

In case of any kind of dissatisfaction, we urge you to Contact us immediately and we shall do our best to help you out.

For any other assistance you can reach us via email.