FILMCITY A7R II Camera Cage kit (FC-A7RS-KIT)

Assembly Manual

◼ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.

Camera cage	Top Handle	Rod Adapter	Sliding base plate	Cable clamp

2x150mm female rods		
2x150mm male rods	MB-600 Matte Box	HS-1000 Follow Focus

■ Matte Box **Setup**

- Insert french flag to the top of Matte Box and tighten it with screws. In the same way, insert side flags into the slots provided on both sides and secure them with screws.


NOTE: If the french flag remains loose even after tightening the knob, then slightly tighten the allen bolt as shown.

- Now wrap Knicker on the conversion ring of Matte Box.

- You can easily insert the filter holders as shown in the image. The Filter tray can be rotated 180 degree.

- The aluminum made Front Adapter attaches matte box to the 15mm rods. Set the matte box at any position on the rods by loosening the knob and sliding along the rails, re-tighten to secure.
NOTE: The Front Adapter also features height adjustment up to 2.5cm increasing compatibility of Matte box to adapt different camera lenses.

■ Camera Cage **Setup**

- Attach the quick release plate of your tripod head with sliding base plate and tighten it with the help of screw driver. Now mount the sliding base plate on fluid head and secure it properly with the help of knob.

- Slide-in the rod adapter into the sliding plate and lock it.

- Now, put the camera into the cage, and secure it properly with ¼"-20 locking screw.

- Put the quick release plate onto the cage and tighten it with locking screw. Then mount the cage onto the rod adapter, and make sure the knob is securely fastened.

- Insert two 15mm rods into the Rod adapter, and tighten the Knobs on both sides of the Rod adapter.

NOTE: You can attach the 150mm male rods at the front to extend the rods for mounting your matte box, follow focus and handles etc.

- Mount the top handle to the Cage as shown in the photo, tighten the knob to secure.

NOTE: You can mount handle at different positions – front / back / side. To do this, loosen the screw with the help of screw driver and set the position as per your requirement, make sure to properly secure it.

- Wrap the flexible gear ring around the camera lens and tighten gear ring's small side knob.

- Loosen the bottom knob of the HS-1000 follow focus and mount it on the rods.

- Tighten both the (side/bottom) knobs of the follow focus to secure it on the rods.

- Insert the Speed crank into the accessory socket of follow focus and secure it correctly.

- Loosen the bottom knob of the follow focus.

- Slide the follow focus ring and join it with the flexible gear ring.

- Once the rings are aligned, securely re-tighten the bottom knob.

Note: The speed crank enables rapid, precise focus rotations that allow the camera lens to zoom and focus simultaneously.

**YOUR FILMCITY A7R II CAMERA CAGE KIT
ALL DRESSED UP AND READY TO GO!**

(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.