

FILMCITY Camera Cage For Sony A7S (FC-A7S-C)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



A7S Camera Cage With Hand Grip



Base Plate



Top Handle



2 x 300mm Female Threaded

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ Camera cage Setup

- Attach the quick release plate of your tripod head with the base plate and tighten it with the help of a screwdriver.
- Now mount the base plate on the fluid head and secure it properly with the help of a knob.
- Insert the rod into the camera base & tighten the knob to secure it.
- Attach the camera with a cage and tighten it with the help of a screw driver.
- Attach the cage with an adapter and tighten it with the knob to secure it.
- Attach the handle with the cage and tighten the knob to secure it properly.



**YOUR FILMCITY CAMERA CAGE FOR SONY A7S
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.