

FILMCITY Camera Cage with Side Handles (FC-A7RS-CSH)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Camera cage



2x side Handle



Cable Clamp

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ Camera Cage with Side Handles Setup

Assemble Camera Cage


- Insert the camera into the cage and tighten it using a screwdriver.



- Slide the handle onto the top of the cage & tighten the knob.




- NOTE:** Loosen the screw using a screwdriver to adjust the direction of the handle or to mount it sideways.



- Similarly, you can mount one more handle on the other side, as shown in the images.



- NOTE:** Cable Clamp has a 1/4" screw and can be attached to any 1/4" thread.



**YOUR FILMCITY CAMERA CAGE WITH SIDE HANDLES
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.