

FLYCAM Arm Brace Support (FLCM-AB)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.

Arm brace foam padding with metal arm support.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ Arm Brace Support Setup

- Open the elastic straps on the support pad.
- Please take off the cover on the metal support arm, place it on the support pad and cover it with elastic straps. Open the Velcro straps and place your arm on the metal arm support base.
- Wrap the arm brace around your arm and Join all the elastic straps with the base Velcro.
- Tighten the Velcro straps to fit the arm brace to your arm securely. Make sure it is comfortable enough for proper blood circulation. Your arm brace is now ready for use.



**YOUR FLYCAM ARM BRACE SUPPORT
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.