

FLYCAM DSLR Camvest - Hands-Free Front & Rear Body Camera Mount Harness (FLCM-CMVT-01)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Flycam DSLR Camvest



Telescopic Arm

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Camvest Setup

- Adjust the buckle of the Camvest per your requirement and attach it as shown in the image.



- Repeat the same process with the upper buckle.

NOTE: You can stretch or loosen the adjustment strap until you feel comfortable.



- Adjust the buckle present on the other side using the strap.

NOTE: It has built-in straps that can be loosened, tightened, buckled, or unbuckled to suit your needs.



Telescopic Arm Assembly

- Loosen and remove the knob of the Telescopic Arm.



- Similarly, remove the second knob of the Telescopic Arm.



- Loosen the center knob of the Telescopic Arm and adjust the rod.



- Insert the Telescopic arm in the Camvest and tighten the knob to secure it, as shown in the image.



- Loosen the front knob of the Telescopic Arm.
NOTE: Its 3ft telescopic pole extension with 180° titling capacity lets you capture footage for multi-dimensional shots.




- The length of the arm can be extended by loosening the knob.
- Mount your Camera (**Not Included**) on the ball head present at the end of the pole.
- NOTE:** There is a ball head at the end of the pole to allow Camera mounting for 180° low & high angled shots.



- After mounting the Camera (**Not Included**), secure it using the provided knob, as shown in the image.
- Adjust the positioning of the Camera according to your need and lock the position with the knob.



- The Camera is fully assembled.
NOTE: Camera (**Not Included**) can be positioned in a POV angle or towards yourself, providing superb third-person shots.



**YOUR PROAIM DSLR CAMVEST - HANDS-FREE FRONT & REAR
BODY CAMERA MOUNT HARNESS
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.