



Flowline Starter with Edge V1 Stabilization Arm (FLCM-FLN-EGV1)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Flowline Starter with Edge Setup

NOTE: It is recommended to attach the minimum required weight (3kg / 6.6lb) for pulling down the balancing rope to ensure proper operation of your Flycam Flowline system.

- Loosen the screw of the Camera Hook attached to the Flowline Support Arm using the Allen key.





- Similarly, remove the second screw.
- Now, remove the Hook from the Flowline Support Arm.



- As shown in the image, take the Cord bundle out from the Cup and pull the Cord until a Cord lock comes out.



- Separate the Cord and the Cord lock.
- Keep the lock aside to re-attach it later.



- Similarly, separate the Cord from the Cup to mount it back later.




- To detach the Flowline Support Rod pull it upwards.



- Disassemble the Camera Hook and the Support Rod from the Vest.



- To detach the extension from the Support Rod of the Vest, remove its screw using a screwdriver.





- Detach the extension from the Support Rod and align the cord with the height riser, **(Not Included)** as shown in the image.



- Attach the extension with the height riser **(Not Included)** and push it inside.

Feature: Height riser that offers up to 4" of vertical extension for taller operators and a lockable hook to secure any camera, gimbal, or cage effortlessly.



- Insert a screw in the Support rod and tighten it using the screwdriver.



- Similarly, tighten the top screw using the screwdriver.
- Loosen the knob of the Flowline Edge.



- After loosening the knob, remove it and pull the rod of Flowline Edge to open it.
Feature: Foldable Design of Flowline Edge makes it easier to store.



- After opening the Rod, insert the knob and properly tighten it, as shown in the image.
Feature: Tension adjustment knob to match your rig's weight, while the adaptable sliding knob adjusts the support rope to your unique filming needs.



- Insert the cord of the Flowline vest in the Flowline Edge.




- After inserting the cord in the Edge, pull the cord from the side of the Rod.




- Properly attach the Edge to the flowline vest.



Feature: It attaches to your Flowline Body Worn Systems like Basic flowline hanger, master flowline hanger, and N series hanger (300N, 400N & 500N) to provide Smooth Floating Shots with utmost comfort.





- Insert the cord into the cup and pull out.



- After inserting the cord in the Cup, pull it outwards and insert it in the Cord Lock.



- After inserting it into the Cup, tie it properly with the Cord Lock.



- Attach the Camera Hook to the Cup.



- Insert the screw into the Camera Hook and secure it properly using an Allen key.
- The Flowline Edge is fully assembled with the Stabilization Arm. The versatile belt system molds to fit all body types.



Capture Every Angle (180° Rotation)



Low/ High Angle Shots



Adjust Camera Setup Position



YOUR FLYCAM FLOWLINE STARTER WITH EDGE V1 STABILIZATION ARM ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.