

# PR◀AIM 19mm Quick Release Camera Base Plate with Dovetail (P-BPDP-19)

---

## Assembly Manual



### ■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Dovetail Tripod Plate



19mm Camera Base Plate



3/8"-16 Screws



1/4"-20 Screws


---

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## ■ Dovetail Plate Setup

- Fix Dovetail Plate to your Tripod Plate and tighten with the help of screw driver.
- Now mount Dovetail Tripod Plate onto Tripod and tighten with provided knob to secure it properly, as shown.
- Slide out the Base plate from the Dovetail Tripod Plate and then push the lever to remove the Base Plate.



## ■ Camera Setup

- Attach the camera with camera base plate and tighten the bolt to secure it. Then Slide your camera onto the dovetail plate & lock with lock lever.



## YOUR PROAIM 19MM QUICK RELEASE CAMERA BASE PLATE WITH DOVETAIL ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.