

# PR<sub>↻</sub>AIM 7' Wave-2 Jib Crane (P-WV-2)

## Assembly Manual



### ■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## ■ Camera Jib Setup

- Insert central fork of Jib arm into bowl of tripod stand, then attach bottom clamp to it for secure connection.



**NOTE:** It is important to make sure that the Central Fork is seated in the bowl properly. That means perpendicular to the tripod bowl. Off axis installation may hamper movement of the jib. Also you may need the assistance of a grip stand to hold the camera end of the arm during installation preventing it from falling as it will be front heavy at this point. You may also need the grip stand or assistance at the rear of the jib when mounting the camera.

- Provided are the jib panning control knobs (as shown in the picture). Loosen the knobs for smooth pan movement of jib and tighten these knobs to lock pan movement of jib.



- Now to extend the rear section of jib, loosen the Allen bolts with provided Allen key and then, loosen the knob as shown in the picture.



- Then, loosen the knob provided at lower telescopic section of jib arm as shown in the picture to extend front section of telescopic jib accordingly to the rear section.



**NOTE:** Make sure the opposite end of the jib arm is secured so that the addition of the weights does not cause the arm to rise violently.

- Attach weight shanks at rear end of jib section by screwing it in and then add weights to it.



- Camera head mount is provided with a knob to control 90° tilt movement of camera. Loosen knob for free tilt movement of camera and tighten it to lock movement.



- Mount your fluid head (Not included) onto the bowl plate in order to attach the camera (Not included). And then finally, secure your camera properly on the fluid Head.



- Loosen the bolts and remove the bowl plate.



- Attach the flat base plate, then attach your pan-tilt head (Not included).



- For the underslung camera setup, attach the flat base plate to the bottom of the jib camera mount and then mount the camera setup. Secure the camera properly.



- For an over slung setup, attach the flat base plate on the top and mount the camera setup and secure the camera properly.



- For 100mm fluid head setup mounting, attach the 100mm bowl on the top, mount the camera setup and secure it properly.



**NOTE:** Jib Section is adjustable, so the balancing chart is flexible, not exact.

## Balancing Tips :

### Self Balance

<b>Length</b>	7 ft	4.10 ft
<b>Weight</b>	2.48 kg	33.45 kg

Camera Weight	Counter Balance	
	7 ft	4.10 ft
1 Kg	3.74 kg	43.32 kg

**YOUR PROAIM 7'WAVE-2 JIB CRANE  
ALL DRESSED UP AND READY TO GO!**



**(SHOWN WITH OPTIONAL ACCESSORIES)**

**Warranty:** We offer a one-year warranty for our products from the date of purchase. Within this period, we will repair it without charge for labor or parts. The warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products we do not supply or from mishandling in transit, accident, misuse, neglect, or lack of care of the product or service by anyone other than our company.

**Contact Us:** If you are dissatisfied, please contact us immediately. We promise our utmost support and care until you use our product.