


Base Workstation for Alpha Stand (TP-ALPA-BW)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Base Workstation Setup

• Remove the bolt of the tray holder using the 6mm Allen key.

• Repeat the same step to remove the remaining bolts.

- **Clamp Assembly**
- Loosen the knob and open the Clamp.

• Now, attach the Clamp to the Tray Holder.

- After attaching the Clamp, insert the bolt and tighten it using the 6mm Allen key.















- The Camp is securely attached to the Tray Holder.
- Repeat the same step to attach the other Clamp.

• Remove the bolt from the Mounting Bracket using the 3/16" Allen Key.

• Repeat the same step to remove the remaining bolts.

- **Mounting Bracket Assembly**
- Attach the Mounting Bracket to the Base Workstation.

• After attaching the Mounting Bracket, carefully insert the bolts by aligning them with the threads and tighten them using the 3/16" Allen key.















- Repeat the same step to insert the remaining bolts.
- The mounting bracket is securely attached to the Base Workstation.

• Slide the Tray Holder with Clamps into the Base Workstation.

• After sliding the Tray holder, lock it securely using the locking knob.

 After locking the tray holder, tighten the locking knob using the 4mm Allen key.
Feature: The Tray Holder, equipped with a pair of quick clamps has a clamping range of 38 to 50mm that attaches to your Alpha Stand.

Base Workstation Assembly

• Mount the Base Workstation onto the Stand (Not Included) and close the clamp.




















- Carefully close the clamp and tighten the knob.
- The Base Workstation is securely mounted onto the Stand.

Feature: The top surface of the workstation is lined with a soft carpet layering and raised lips to prevent any scuffing of your gear.

Feature: The positioning of the Workstation can be set per your requirement with its 360° rotation and adjustable sliding feature.











Screen Setup

• Loosen the knob of the screen (Not included) and mount it on the Stand (Not Included).



- Tighten the knob after mounting the screen.
- The Screen is securely mounted on the Stand.





Feature: It features a pass-through hole for cables, allowing you to seamlessly manage cables from equipment, such as a keyboard or mouse.



YOUR PROAIM BASE WORKSTATION FOR ALPHA STAND ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.