

PR◊AIM Cart Docking Bracket for Flowline Body Support Rigs (FLN-CTDB)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Cart Docking Bracket



Support Bar Clamp



Conversion Adapter

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ Cart Docking Bracket Setup


- Attach the docking bracket on the cart edge and tighten the knob to secure it appropriately.



- Remove the side bolts of the support bar clamp using a 3mm allen key and separate both the parts.



- Slide and Insert one part of the support bar clamp into the docking bracket.



- Align and fix the conversion adapter to the support bar clamp as shown in the image.



NOTE: You use Conversion adapters only to mount the Flycam Basic Flowline Rig Jacket, as it has a small diameter. Otherwise, a large-sized jacket fits easily without a conversion adapter.

Compatibility: Flycam Flowline Body Support Stabilizer Rigs
Proaim Victor, Victor V1.1 Series Carts

- Attach the Flycam Basic Flowline rig to the support bar clamp on the cart.



- Align and attach the second part of the support bar clamp to the flycam basic flowline rig.



- Use a 3mm Allen Key to secure both the clamp parts together.



- Proaim Cart Docking Bracket for Flowline Body Support Rigs setup is ready.



**YOUR PROAIM CART DOCKING BRACKET FOR FLOWLINE BODY SUPPORT RIGS
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.