

### Assembly Manual



### ■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Cinema Vest



Cinema Arm



Hip Pad



Bag Packing

---

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

# INDEX

<b>Sr. No</b>	<b>Particulars</b>	<b>Page No.</b>
1	Cinema Vest Assembly	1-4
2	Hip Pad Assembly	4
3	Cinema Arm Assembly	5-6
4	Zest Pro Electronic Stabilizer Setup	6-7
5	Adjusting Arm's Position	7
6	Final Setup	8


## Cinema Arm & Vest Setup

### Cinema Vest Assembly

- Attach the front and back sides of the Cinema Vest using the Buckle.



- To attach the second Buckle, repeat the same process.



- Now, wear the Vest.



- Attach the Ratchet buckle of the Vest, as shown in the image.


**Feature:** This Vest features a unique Ratchet Buckle at the waist for adjustable fitting.



- After attaching the Ratchet buckle, properly lock it.
- Attach the second Buckle, repeating the same process.



- Open the Velcro of the shoulder strap and pull it per your requirement.



- After pulling the shoulder strap, properly paste it.
- Repeat the same process for the second side.

**NOTE:** You can tighten or loosen the adjustment strap of the jacket until you find it comfortable.



- Using the Pull Pin, adjust the height of the Slider Plate per your requirement.



## Hip Pad Assembly

- Attach the Hip Pad to your waist and overlap its Velcro from both sides, suiting your comfort.

**NOTE:** Make sure the Hip straps are horizontal on the Pads and tighten them evenly.



**NOTE:** We've also included waist padding made from fiber sheets, ensuring a more personalized fit.



# Cinema Arm Assembly



- Loosen the knobs of the Socket Block, as shown in the image.



- Properly insert the male connecting Socket of Cinema Arm into the Socket Block.





- After inserting the male Socket knob, re-tighten the knobs of the Socket Block.
- Your Cinema Arm is securely attached, as shown in the image.





**Feature: 1.** You can conveniently loosen or tighten its tension for optimal performance.  
**2.** It is designed with dual springs for silky smooth operation.




**NOTE:** Adjust the Arm section nearest to the stabilizer first and then the second section of the arm.

- Loosen the first Spring Tension Adjustment knob of the Cinema Arm to balance the upper section of the Arm per your requirement and re-tighten the knob.



- To balance the lower Arm Section, loosen the second Spring Tension Adjustment knob and adjust the Arm per your requirement.



## Zest Pro Electronic Stabilizer Setup

**NOTE:** When attaching the stabilizer to the Arm and Vest, keep the Stabilizer's handle straight in accordance with the Pin of the Arm.

**Feature:** The Cinema Arm features a 16mm post for Stabilizers, making it compatible with most Stabilizers.



- Insert the Zest Pro Electronic Stabilizer (Not Included) into the Arm Post of the Cinema Arm.



- The Zest Pro Stabilizer is properly attached to the Cinema Arm, as shown in the image.



## Adjusting Arm's Position

- Loosen the knob and pull the Pull Pin.



- Remove the Socket Block and adjust it to the left or right position with the provided knob, as shown in the image.



- After adjusting the position of the Socket Block, slide it on the Slider Plate.



- After sliding the Socket Block onto the Slider Plate, properly tighten the knob and lock it in position using the Pull Pin.



- **Feature:** It can be effectively operated via a right-handed or left-handed operator.



## YOUR PROAIM CINEMA ARM & VEST FOR HANDHELD CAMERA STABILIZERS ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.