
PR → A | M Dovetail Camera Shoulder Mount Rig (SR-250-00)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Shoulder Mount Rig **Setup**

 Attach the ARRI standard rosette handles to the Rosette crossbar and secure them using the knob as shown in the images.





• Slide the Dovetail Quick Release plate on the threaded crossbar.





• Adjust the Dovetail Quick Release plate and secure it correctly with the help of a knob.



• Slide in the shoulder pad to the dovetail quick release plate as shown in the images.





• Secure it correctly using the locking lever.



• Loosen the side rotation knobs present on both sides of the Rosette crossbar, and you can rotate the handles up to 360°.





 Adjust the handles and lock them at the desired position using a knob.



• Loosen the height adjustment knobs present on both handles, and you can adjust the height up to 50mm.





• Tighten the knob to lock the handles at the desired height.



• Loosen the lower side rotation knobs, and you can rotate the handgrips up to 180°.





• Loosen the rotation knobs present on the bottom of the crossbar to narrow down or widen the space between the handles.



• Narrow down or widen the handles as per your preference.





 Loosen the dovetail plate knob for quickly moving the dovetail plate on the threaded crossbar.



• You can now adjust the plate at your desired position, as shown in the images.





• Push the pin in and remove the Base plate from the Dovetail plate as shown.





• Loosen the rod adapter's bolt using an 3/16mm Allen key. Now, attach the rod adapter to the Base plate.





• Insert the bolt into the Base plate and tighten it using the 3/16mm Allen key.





• Mount your Camera on the Base plate and secure the bolt using an Allen key.





• Slide the base plate with the Camera mounted on it on the dovetail plate and press the Locking lever to secure it.





• Your setup is ready.



YOUR PROAIM DOVETAIL CAMERA SHOULDER MOUNT RIG ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.