

# Gladiator Ergonomic Body Support Camera Rig (P-GDTR-01)

## Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## Gladiator Rig Setup

- To adjust the shoulder pad position, loosen the top front & back screws using an Allen key and adjust the shoulder pad as required.

**Note:** You can move the screws up and down by loosening them. Moving the screw up helps you extend the shoulder post upwards. Lowering the screw lowers the shoulder pad.

- Retighten the screws using an Allen key to secure the shoulder pad position.

- Loosen both the front and back height adjustment knobs on the jacket.

- Adjust the height as required and retighten the knobs properly. Then detach the waist buckle.

**Note:** The jacket quickly adjusts to fit different body types and changes on the fly to keep you comfortable take-after-take.

- Detach the chest buckle and wear the gladiator jacket on your right shoulder. Then, reattach the waist buckle.

**Note:** The gladiator jacket comes assembled on the right side. If you want to wear it on the left side according to your requirement, its steps are given separately.

- Buckle up the chest strap as shown in the image.

**Note:** You can adjust the chest strap as per your comfort.



## Gladiator Rig Left shoulder Setup

**Note:** If you don't interchange the shoulder support plate of the gladiator rig and wear it on the left shoulder, the gladiator jacket will not adjust on your body, and the pad will go to the back wrong side.

The steps to mount the pad correctly are given below.

- Loosen and take off both the height adjustment knobs.



### Shifting the Middle Plate & Pad

- Remove the jacket's middle plate and shift it along with the pad from one side to the other.



- Attach the middle plate and tighten the knobs back securely.



### Interchanging Shoulder Support from Right to Left

- Loosen all bolts on the front and back sides of the jacket using an Allen key.



- You can adjust the bottom plate of the jacket anywhere on the rear-strut.



- Shift the bottom plate of the jacket from one side to the other and tighten all the bolts using an Allen key, as shown in the image.

**Note:** Follow the same process on the other side of the jacket.



- Buckle up and adjust the chest and the waist straps as per your comfort.



**Note:** Proaim Gladiator Rig prevents spinal compression allowing you to comfortably operate shoulder-mounted configurations without affecting the camera's movement or balance. 100% of the weight is transferred from your shoulders and back to your hips, bypassing your spine.

It supports heavy-duty loads, such as fully-accessorized ARRI, Red or Black Magic Cameras.



## YOUR PROAIM GLADIATOR BODY SUPPORT CAMERA RIG ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.