



HD 100mm Bowl Baby Camera Tripod Stand w Lever-Friction and Aluminum Spreader (P-LLBT-100)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



HD 100mm Bowl Baby Camera Tripod Stand
with Lever Friction



Aluminum Spreader



Spanner Size: 13mm

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Aluminum Spreader Setup

- Extend the Spreader on the floor and loosen all three knobs.

NOTE: The Spreader attaches to the spiked legs of the spreader to provide precise customization of the tripod's length and stability.

- After loosening the knobs, extend the Spreader per your requirement.
- You can lock the position using the locking knobs present on each arm.

NOTE: The arms of the Spreader can easily telescope out from 41cm/16" to 66cm/26" radius, offering a broader footprint to create a secure and steady base for the tripod.



Extendable adjustment via the provided locking knobs of Spreader



100mm Bowl Baby Camera Tripod Stand Setup

- Loosen all three adjustment knobs to set the desired height of the Stand.

NOTE: One-stage telescopic design with friction knob extends up to 6 inches to capture low-angle shots, and conversely, it can be easily extended up to 34 inches for greater elevation.



- After setting the height, tighten the knobs to secure the Stand, as shown in the image.

NOTE: Locking pins on each leg secure the adjusted height, preventing them from retracting under load.



- Unlock the red knob to adjust the Tripod's legs according to your requirement.



- After adjusting the Tripod legs, re-lock the knob, as shown in the image.



- Mount the Tripod on the aluminum Spreader by equally aligning them.



- After mounting the Tripod, properly secure it using the rubber gripper.



- Loosen the locking knob of the 100mm bowl fluid head (**Not Included**) and remove it.
- Now, mount the fluid head on the Tripod Stand.



- Tighten the locking knob to secure the fluid head.



- Press the red locking lever of the fluid head (**Not Included**) to unlock it.
- After unlocking the yellow locking lever, remove the top plate of the fluid head



- Attach it to the Camera (**Not Included**) by matching the threads.
- Secure the top plate and the Camera (**Not Included**) using a screwdriver.



- Now, mount the Camera (**Not Included**) on the fluid head and properly lock it as shown in the image.



NOTE: The assembly of the whole setup is quick and tool-less, saving you valuable production time.

- Tripod Stand works efficiently with compatible devices such as Sliders, Jibs, and Geared Heads with its 100mm bowl base.



**YOUR PROAIM HD 100MM BOWL BABY CAMERA TRIPOD STAND W
LEVER-FRICTION AND ALUMINUM SPREADER
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.