

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



150mm Camera Tripod Stand



Aluminum Tripod Spreader

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Aluminum Tripod Spreader Setup

 Firstly, take out the Aluminium tripod spreader, spread it on the floor and then open its legs (as per your requirement) and secure with the help of provided knobs.





150mm Camera Tripod Stand

 Take out the Aluminum Tripod Stand, spread the stand legs over its spreader and secure it with the provided knob.



 After mounting the Aluminum Tripod Stand lock it in place with the rubber grips as shown in the image.





 To adjust the height of the tripod, loosen all three adjustment knobs. You can adjust the tripod up to the desired height and then re-tighten the knobs securely.





• At last, your Tripod Stand with Spreader is fully assembled as shown in the image.



YOUR PROAIM HEAVY DUTY CAMERA TRIPOD STAND ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty for our products from the date of purchase. Within this period, we will repair it without charge for labor or parts. The warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

Liability: We are not liable for damage caused by products we do not supply or from mishandling in transit, accident, misuse, neglect, or lack of care of the product or service by anyone other than our company.

Contact Us: If you are dissatisfied, please contact us immediately. We promise our utmost support and care until you use our product.