

# Quad Plus Film Camera Doorway Dolly (P-QUAD-PL)

## Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Steering Push/ Pull Bar



Proaim Quad Plus Professional Dolly



Bowl-Camera Riser



Allen Bolt



Lock Nut



Washer



Proaim Telescopic Bazooka & Proaim Euro Adapter


All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright

## ■ Quad Plus Setup

### Assemble Push/Pull Bar

- Insert the bolt matching the hole of the dolly and secure it with the help of a washer then position the steering push/pull bar to the center of the dolly.
- Connect the push/pull bar using an allen bolt with washer and locknut.
- Secure the allen bolt and washer with a allen key as shown in the image.




**Note:** You can adjust the tilt of the steering push/pull bar up to 270°





### Assemble Euro Adapter

- Mount the Euro adapter on the Dolly platform aligning the Euro thread holes with dolly holes.
- Insert the washer matching the Euro mount hole and then secure the Euro with bolts as shown.




- Now Secure your Euro Adapter, tighten the bolts with the help of Allen key.



## Bazooka Setup

- Mount the Bazooka onto the euro adapter, as shown in the image.




- After Mounted the bazooka, Lock the inner knob to secure the bazooka. The knob rotate anti-clockwise. (Do not over tighten the knob). Lock the lever for more security.

**Note:** The Quick-Lock Lever ensures a secure bazooka lock-off when mounted on a dolly system.



## Assemble Riser

- Mount the bowl camera riser onto the bazooka adapter, as shown in the image.




- Now tighten the ratchet knob of the riser then tighten the bazooka ratchet knob to fix the riser perfectly onto the bazooka.



- Riser is properly secure shown in the image.




- You can adjust the bazooka height using the provided bazooka ratchet knob.



- To increase or decrease the length of the tire, first loosen the bolt with the help of a wrench.

**Note.** The width of the tire can be Increased/ decreased via telescopic rear axle.



## YOUR PROAIM QUAD PLUS FILM CAMERA DOORWAY DOLLY ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.