

# Quick Release Mount for Freefly MOVI, DJI Ronin/M/MX Camera Gimbals (QR-WV-710)

#### Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



**Quick Release Mount** 



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

#### Quick Release Mount Setup

• To remove the bowl from the Jib (Not Included), remove both bolts from the bottom, as shown in the image.





• Loosen both bolts from the bottom of the Quick Release Mount using the Allen key.





- After loosening the bolts, remove them.
- Mount the Quick Release Mount on the Wave Jib (Not Included) by matching the threads.





Mount the Quick Release Mount.
NOTE: Quick Release Mount lets you mount your camera gimbal on various platforms.



 After mounting, insert bolts from the bottom and tighten them using the Allen key.





• The Quick Release is properly mounted on the Jib (Not Included).



• The Quick release can also be mounted from the bottom side of the Jib (Not Included), as shown in the image.





• After inserting the bolts, tighten them using the Allen key.





 Unlock the locking lever of the Quick release and slide the Gimbal (Not Included) by pushing its button.

**NOTE:** It has a locking lever to tighten the camera base adapter providing a secure gimbal camera setup.





 After sliding the Gimbal (Not Included) onto the Quick Release, then re-lock the Locking Lever.





 Secure the setup by tightening all screws using the Allen key.

**NOTE:** Quick Release Mount is compatible with standard grip-related cheese plates used on Gears like Jibs, Cranes, Vehicular Mounting, etc.





## YOUR PROAIM QUICK RELEASE MOUNT ALL DRESSED UP AND READY TO GO!



#### (SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.