

PROAIM SnapRig Cage for Sony a7S III Top Handle (CG215)

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Proaim SnapRig Cage CG215



Top Handle



1 x 1/4" - 20 Screw

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

■ Camera Cage Setup

- Attach the handle to the top mounting center thread hole of the SnapRig cage, then tighten it correctly using the handle knob.



- Image showing top handle correctly attached to the cage.



- Securely insert the camera (Not Included) in the SnapRig cage. Align the Camera hole to the screw hole at the bottom of the cage and insert the screw.



- Tighten the screw properly using a screw-driver, ensuring the camera is well secured in the cage.



NOTE: Removable ARRI rosette allows the top handle to be oriented 360° forward and back.



**YOUR PROAIM SNAPRIG CAGE FOR SONY A7S III WITH TOP HANDLE
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.