


# PR◊AIM Universal Tablet Teleprompter Kit (P-TP300)

## Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Teleprompter Glass



iPad tray



Black Cloth with  
Camera Knicker



15mm Rods



Camera Mounting Base with  
Metal Quick Release Plate



Allen Keys



4X Bolts



Dusting Cloth



Cotton Fabric  
Hand Gloves



Hard Case

**NOTE:** The teleprompter glass has a different amount of reflectivity at both ends. If the glass is not installed in proper orientation than you may experience a "double image" or "text shadow" effect on the teleprompter. To eliminate this, we have applied a Red sticker on the front side of the glass. In case, the mark gets removed and you face this issue, simply flip the teleprompter glass.

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## Teleprompter Setup

- Mount camera mounting base with Metal quick release plate on your tripod stand (**Not Included**) and tighten with twisting.



- Loosen the knobs of camera mounting base, Insert 15mm rods and tighten the knobs at both side to secure the rods properly.



- Loosen the screw of the teleprompter glass frame using a screwdriver and remove the glass security latch.



- Fit the glass into the teleprompter and secure it with the glass security latch as shown in the image.



- Image showing properly fitted glass.



- Attach prompter glass to iPad tray and tighten the screws with the help of allen key.
- Attach hood outside prompter glass. Close the zip of hood from both sides to avoid unwanted light.
- Now insert the prompter glass with iPad tray to 15mm rods and tighten the knobs to secure it properly.
- Remove Metal quick release plate from camera mounting base for attaching camera, putted bag and secure properly.



**YOUR PROAIM UNIVERSAL TABLET TELEPROMPTER KIT  
ALL DRESSED UP AND READY TO GO!**



**(SHOWN WITH OPTIONAL ACCESSORIES)**

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.