

# Height Adjustable Telescopic Poles for Atlas carts (ATLS-HAP)

## Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



4 x Height Adjustable Telescopic Poles

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

## Telescopic Poles Setup

- Open the lock at all corners of the top shelf of the Atlas cart (**Not Included**).



- Now, remove the top shelf by lifting it upwards.

**NOTE:** Two people are required to detach the top shelf from the foldable rods.



- After removing the top shelf, loosen and remove the bolts of the rod from the bottom shelf using 3mm Allen key.



- Thus, repeat the same process for other corners as well.



- Now, loosen the bolts of the lock using 4mm Allen key, as shown in the image.
- Remove the lock from the cart.



- Similarly, remove the remaining three locks.



- Now, loosen and remove the bolts from the shelf.
- Follow the same steps to remove the remaining bolts at other corners as well.



- Now, open the lock near the wheel, under the shelf.



- Slide the wheel to backward.
- Then, turn the cart to one side.



- Fix the wheel by locking it.



- Loosen and remove the bolts on the bottom shelf using 4mm Allen key.



- Similarly, follow the same steps to remove the rods from all corners.



## Removal of Rod from Adaptor

- Loosen bolts using 5mm Allen key from the Rod Adaptor.



- Now remove the bolts from the Rod Adaptor.



- Push the sank from the Adaptor using any Allen key .



- Remove the sank from the Adaptor.



- Loosen the knob of the Adaptor and open its lock.



- Now, remove the rod from the Rod Adaptor.



## Telescopic Pole Assembly

- Insert Rod Telescopic Pole to the Rod Adaptor.
- Insert one washer on the left side of the pole.



- Insert the sank from the same side of the washer.



- Insert the other washer on the right side of the pole.



- Push the sank to the inner side of the Adaptor and insert the bolt on the other side.



- Tighten the bolt using 5mm Allen key.





- Close the lock and the knob to secure the pole in the Adaptor.



- Attach the Adjustable Telescopic Pole to the bottom shelf of the Atlas cart.
- After attaching the Pole, insert the bolt, as shown in the image.



- After inserting the bolt, tighten it using the 3mm Allen key.



- Insert all 4 bolts on the back side of the shelf, tighten it using the 4mm Allen key.



- Now, insert the bolt of the lock, tighten it using the 4mm Allen key.



- Repeat the process for other poles as well.



- Now, open the lock near the wheel, under the shelf.



- Slide the wheel to backward.
- Then, turn the cart to one side.



- Fix the wheel using lock.



- Insert the bolt on the bottom of the shelf, tighten it using the 4mm Allen key.



- After turning the cart again to the previous position, remove the knob fixed in the adjustable pole by loosening it.



- After that, adjust the height of the telescopic pole according to the requirement.
- Insert the knob in the provided hole at the desired height, as shown in the image.
- Tighten the knob to secure the attachment.



- Similarly, follow the same steps to attach the remaining poles.

**Features:** The height of the top shelf can be adjusted from 2.46 feet / 29.5" to 1.67 feet / 20"



- Mount the top shelf of the Atlas cart on the rod.



- Now, lock the shelf at all corners to secure the attachment.
- Your cart is fully assembled with adjustable telescopic poles.



## Height Range- 2.46ft / 29.5" To 1.67ft / 20"





**YOUR PROAIM HEIGHT ADJUSTABLE TELESCOPIC POLES FOR ATLAS CARTS  
ALL DRESSED UP AND READY TO GO!**



**(SHOWN WITH OPTIONAL ACCESSORIES)**

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.